

MITSUBISHI ELECTRIC
INSTALLATION MANUAL

SPLIT-TYPE AIR CONDITIONERS
 Models **MS-GA80VB**
MSH-GA80VB Series
MSH-GA60VB
 [FLARE CONNECTION TYPE]

HFC utilized R410A

When installing an MKZ series outdoor unit, refer to the MS and MSH type manual for indoor unit set up.

1. THE FOLLOWING SHOULD ALWAYS BE OBSERVED FOR SAFETY

- Please provide an exclusive circuit for the air conditioner and do not connect other electrical appliances to it.
- Please refer to your supply authority or obtain their consent before connecting this equipment to the power supply system.
- Be sure to read "THE FOLLOWING SHOULD ALWAYS BE OBSERVED FOR SAFETY" before installing the air conditioner.
- Be sure to observe the cautions specified here as they include important items related to safety.
- The indications and meanings are as follows.

CAUTION
 Could lead to death, serious injury, etc.

CAUTION
 Could lead to serious injury in particular environments when operated incorrectly.

After reading this manual, be sure to keep it together with the OPERATING INSTRUCTIONS in a handy place on the customer's site.

WARNING
 Do not install the unit by yourself (customer). Incomplete installation could cause injury due to fire, electric shock, the unit falling or leakage of water. Consult the dealer from whom you purchased the unit or special installer.

WARNING
 Install the unit securely in a place which can bear the weight of the unit. When installed in an insufficient strong place, the unit could fall causing injury.

WARNING
 Use the specified wires to connect the indoor and outdoor units securely and attach the wires firmly to the terminal block connecting sections so the stress of the wires is not applied to the sections. Incomplete connecting and fixing could cause fire.

WARNING
 Do not use intermediate connection of the power cord or the extension cord and do not connect many devices to one AC outlet. It could cause a fire or an electric shock due to defective contact, defective insulation, exceeding the permissible current, etc.

WARNING
 Check that the refrigerant gas does not leak after installation has completed. If refrigerant gas leaks indoors, and comes into contact with the fire of a fan heater, space heater, stove, etc., harmful substances will be generated.

WARNING
 Perform the installation securely referring to the installation manual. Incomplete installation could cause a personal injury due to fire, electric shock, the unit falling or leakage of water, etc.

WARNING
 Perform electrical work according to the installation manual and be sure to use an exclusive circuit. If the capacity of the power circuit is insufficient or there is incomplete electrical work, it could result in a fire or an electric shock.

WARNING
 Attach the electrical cover to the indoor unit and the service panel to the outdoor unit securely. If the electrical cover in the indoor unit and/or the service panel in the outdoor unit are not attached securely, it could result in a fire or an electric shock due to dust, water, etc.

WARNING
 Be sure to use the part provided or specified parts for the installation work. The use of defective parts could cause an injury or leakage of water due to a fire, an electric shock, the unit falling, etc.

WARNING
 Be sure to cut off the main power in case of setting up the indoor electronic control P.C. board or wiring works. It could cause an electric shock.

WARNING
 The appliance shall be installed in accordance with national wiring regulations.

WARNING
 When installing or relocating the unit, make sure that no substance other than the specified refrigerant (R410A) enters the refrigerant circuit. Any presence of foreign substance such as air can cause abnormal pressure rise or an explosion.

3. INSTALLATION DIAGRAM & ACCESSORIES

FLARED CONNECTIONS
 This unit has flared connections on both indoor and outdoor sides.
 Remove the outdoor units valve cover, then connect the pipe.
 Refrigerant pipes are used to connect the indoor and outdoor units.
 Be careful not to crush or bend the pipe or pipe bending.

Limits	MSH-GA60	MS(H)-GA80
Pipe length	25 m max.	30 m max.
Height difference	10 m max.	15 m max.
No. of bends		10 max.

Refrigerant adjustment... If pipe length exceeds 7 m, additional refrigerant (R410A) charge is required. (The outdoor unit is charged with refrigerant for pipe length up to 7 m.)


Pipe length	MS-GA80	MSH-GA80
Up to 7 m	No additional charge is required.	No additional charge is required.
Exceeding 7 m	Additional charge is required. (Refer to the table below.)	Additional charge is required. (Refer to the table below.)

Refrigerant to be added

Accessories	Quantity
Installation plate	1
Installation plate fixing screw 4 x 25 mm	7
Remote controller holder	1
Fixing screw for φ 3.5 x 16 mm (Black)	2
Battery (AAA) for remote controller	2
Wireless remote controller	1
Felt tape (Used for left or left-rear piping)	1

Optional extension pipe


Indoor/outdoor unit connecting wire (2-core 1.0 mm ² -2.0 mm ²)	1
Extension pipe	1
Wall hole sleeve	1
Wall hole cover	1
Pipe fixing band (The quantity depends on the pipe length.)	2 to 5
Fixing screw for φ 4 x 20 mm (The quantity depends on the pipe length.)	2 to 5
Piping tape	1
Putty	1
Drain hose (or soft PVC hose, 15 mm inner dia. or hard PVC pipe VP16)	1
Refillation oil	1
Power supply cord (See the table in 5 INDOOR/OUTDOOR WIRE CONNECTION AND OUTDOOR POWER SUPPLY CORD CONNECTION for the cord size.)	1



Units should be installed by licensed contractor according to local code requirement.


4. INDOOR UNIT INSTALLATION

4-1 FIXING OF INSTALLATION PLATE
 Find a structural material (such as a stud) in the wall and fix installation plate horizontally.




When bolts recessed in the concrete wall are to be utilized, secure the installation plate using 11 x 20 - 11 x 25 oval hole (450 mm pitch). If the recessed bolt is too long, change it for a shorter one available in the market.

4-2 WALL HOLE DRILLING
 Determine the wall hole position.
 Drill a 75 mm hole so that outside can be lower than inside.
 Insert the wall hole sleeve.




Positioning of the holes on the wall
 The distance between the holes should be 100 mm.



Be sure to use wall hole sleeve to prevent the outdoor connecting wires from contacting with metal part in the wall and to prevent damage by rat in case the wall is hollow.

Wall hole sealing and fixing pipe to wall
 Seal the wall hole gap with putty. Cut off the extra length. Use a pipe fixing band.



Be sure to use the insulation of specified thickness. Excessive thickness may cause incorrect installation of the indoor unit and lack of thickness may cause dew dripage.

CAUTION
 Be sure to use the insulation of specified thickness. Excessive thickness may cause incorrect installation of the indoor unit and lack of thickness may cause dew dripage.

CAUTION
 Be sure to use the insulation of specified thickness. Excessive thickness may cause incorrect installation of the indoor unit and lack of thickness may cause dew dripage.

6. INDOOR/OUTDOOR UNIT CONNECTION FINISHING AND TEST RUN


INSTALLATION INFORMATION FOR THE AIR CONDITIONER WITH R410A REFRIGERANT
 This room air conditioner adopts an HFC refrigerant (R410A) which will never deplete the ozone layer.

- Pay particular attention to the following points, though the basic installation procedure is same as that for R22 air conditioners.
- As R410A has a working pressure approx. 1.6 times as high as that of R22, some special tools and piping parts' materials are required. (Refer to the table below.)
- For refrigerant piping, use clean, pressure-proof parts / materials specifically designed for R410A. (Refer to 2. Refrigerant piping.)
- Composition change may occur in R410A since it is a mixed refrigerant. When charging, charge liquid refrigerant to prevent composition change.

6-1 Tools dedicated for the air conditioner with R410A refrigerant
 The following tools are required for R410A refrigerant. Some R22 tools can be substituted for R410A tools.

R410A tools	Can R22 tools be used?	Description
Gauge manifold	No	R410A has high pressures beyond the measurement range of existing gauges. Port diameters have been changed to prevent any other refrigerant from being charged into the unit.
Charge hose	No	Hose material and cap size have been changed to improve the pressure resistance.
Gas leak detector	No	Dedicated for HFC refrigerant.
Torque wrench	Yes	1/4" and 5/8"
Flare tool	Yes	Clamp bar hole has been enlarged to reinforce the spring strength in the tool.
Flare gauge	New	Provided for flaring work (to be used with R22 flare tool).
Vacuum pump adaptor	New	Provided to prevent the back flow of oil. This adaptor enables you to use existing vacuum pumps.
Electronic scale for refrigerant charging	New	It is difficult to measure R410A with a charging cylinder because the refrigerant bubbles due to high pressure and high-speed vaporization.

No. Not substitutable for R410A. Yes: Substitutable for R410A.



6-2 FLARING WORK
 Main cause of gas leakage is defect in flaring work. Carry out correct flaring work in the following procedure.

- 1. Pipe cutting
 Cut the copper pipe correctly with pipe cutter.
- 2. Burrs removal
 Completely remove all burrs from the cut cross section of pipe. Put the end of the copper pipe to downward direction as you remove burrs in order to avoid to let burrs drop in the piping.
- 3. Putting nut on
 Remove flare nuts attached to indoor and outdoor units, then put them on pipe having completed burr removal. (not possible to put them on after flaring work.)
 Flare nut for R410A pipe differs from R22 pipe. Refer to the following table for detail.

mm	inch	R410A	R22
ø6.35	1/4	17	17
ø9.52	3/8	22	22
ø15.88	5/8	29	27

6-3 PIPE CONNECTION
 Note:
 Fasten a flare nut with a torque wrench as specified in the table below. When fastened too tight, a flare nut may be broken after a long period and cause a leakage of refrigerant.

6-4 PURGING PROCEDURES-LEAK TEST
 Purging procedures:
 Connect the refrigerant pipes (both liquid pipe and the gas pipe) between the indoor and the outdoor unit.
 Remove the service port cap of the stop valve on the side of the outdoor unit gas pipe. (The stop valve will not work in its initial state fresh out of the factory (totally closed with cap on).)
 Run the vacuum pump. (Vacuumize for more than 15 minutes.)
 Check the vacuum with the gauge manifold valve, then close the gauge manifold valve, and stop the vacuum pump.
 Leave as it is for one or two minutes. Make sure the pointer gauge manifold valve remains in the same position. Confirm that the pressure gauge shows -0.101 Mpa (Gauge) (-760 mmHg).

6-5 TEST RUN
 MS type
 Before performing the test run, check for any wrong wiring. Wrong wiring prevents normal operation or results in blown fuse disabling operation. The test run can be started by pressing EMERGENCY OPERATION switch. When the EMERGENCY OPERATION switch is once pressed, the unit will start the test run (continuous operation) for 30 minutes. A thermostat does not work during this time. After 30 minutes the unit will start the EMERGENCY OPERATION at a fixed temperature setting of 24°C in COOL MODE. Perform test run in the following procedure.

6-6 EXPLANATION TO THE CUSTOMER
 Using the OPERATING INSTRUCTIONS, explain the following to the customer, how to control temperature, how to remove the air filters, how to remove or put the remote controller in the remote controller holder, how to clean, precautions for operation, etc. Recommend the customer to read the OPERATING INSTRUCTIONS carefully.

4-3 CONNECTING WIRE SPECIFICATIONS


Use special room air conditioning circuit.
 Power supply cord length (Lead to left/Lead to right) 1 m/2 m
 Indoor/outdoor unit connecting wire Specification Cable 2-core 1.0 mm², in conformity with Design 245 IEC 57.

Take out power supply cord from the left or right bottom corner of the indoor unit.

Connect to the power switch which has a gap of 3 mm or more when open to interrupt the source power phase. (When the power switch is shut off, it must interrupt all phases.) (Rated Voltage/Frequency: 230 V/50 Hz) (Input capacity: Main switch/Fuse: 10 A) (This plug has to be the one meets the Standards.)
 Power supply cord
 Green/Yellow - Ground
 Blue - N
 Brown - L


WARNING
 Never cut the indoor and outdoor unit connecting wire and connect it to other wires. It may cause a fire.

Do not bundle the spare wire, but put it as shown below.



4-4 INDOOR AND OUTDOOR CONNECTING WIRE CONNECTION


You can connect indoor/outdoor lead wire without removing the front panel.
 1. Open the front panel.
 2. Remove one screw holding the electrical cover, then remove the cover.
 3. Remove the VA clamp and the cord clamp.
 4. Pass the indoor/outdoor unit connecting wire from the back of the indoor unit and process the end of the wire, then connect it to the terminal block.
 5. Replace the fixture and electrical cover securely.



WARNING
 Use the indoor/outdoor unit connecting wire that meets the Standards to connect the indoor and outdoor units and fix the wire to the terminal block securely so that no external force is conveyed to the connecting section of the terminal block. Incomplete connection or fixing of the wire could result in a fire.

Attach the electrical cover securely. If it is attached incorrectly, it could result in a fire or an electric shock due to dust, water, etc.

MS Type and MSH Type
 Indoor terminal block: 3 N
 Outdoor terminal block: 3 N



Loosen terminal screw. Indoor/outdoor unit connecting wire (2-core 1.0 mm²). Lead wire. Fixing screw.

Connect the refrigerant pipes (both liquid pipe and the gas pipe) between the indoor and the outdoor unit.

Remove the service port cap of the stop valve on the side of the outdoor unit gas pipe. (The stop valve will not work in its initial state fresh out of the factory (totally closed with cap on).)

Run the vacuum pump. (Vacuumize for more than 15 minutes.)

Check the vacuum with the gauge manifold valve, then close the gauge manifold valve, and stop the vacuum pump.

Leave as it is for one or two minutes. Make sure the pointer gauge manifold valve remains in the same position. Confirm that the pressure gauge shows -0.101 Mpa (Gauge) (-760 mmHg).

6-5 TEST RUN
 MS type
 Before performing the test run, check for any wrong wiring. Wrong wiring prevents normal operation or results in blown fuse disabling operation. The test run can be started by pressing EMERGENCY OPERATION switch. When the EMERGENCY OPERATION switch is once pressed, the unit will start the test run (continuous operation) for 30 minutes. A thermostat does not work during this time. After 30 minutes the unit will start the EMERGENCY OPERATION at a fixed temperature setting of 24°C in COOL MODE. Perform test run in the following procedure.

6-6 EXPLANATION TO THE CUSTOMER
 Using the OPERATING INSTRUCTIONS, explain the following to the customer, how to control temperature, how to remove the air filters, how to remove or put the remote controller in the remote controller holder, how to clean, precautions for operation, etc. Recommend the customer to read the OPERATING INSTRUCTIONS carefully.

4-5 AUTO RESTART FUNCTION

These models are equipped with an auto restart function. If you do not want to use this function, please contact the service representative because the setting of the unit needs to be changed.
 When the indoor unit is controlled with the remote controller, the operation mode, set temperature, and the fan speed are memorized by the indoor electronic control P.C. board. The auto restart function sets to work the moment the power has been restored after power failure, then the unit will restart automatically. If the unit is operated in "FEEL" or "AUTO" mode before power failure, the operation mode (COOL, DRY or HEAT) is not stored in the memory. When the main power is turned on, the unit decides the operation mode by the initial room temperature at restart and starts operation again.

Operation
 1. If the main power has been cut, the operation settings remain.
 2. When three minutes have passed after power was restored, the unit will restart automatically according to the memory.

Notes:
 1. The operation settings are memorized when 10 seconds have passed after the remote controller was operated.
 2. If the main power is turned off by a power outage occurs while AUTO START/STOP timer is active, the timer setting is cancelled. As these models are equipped with an auto restart function, the air conditioner starts operating with timer cancelled at the same time that power is restored.
 3. If the unit has been off with the remote controller before power failure, the auto restart function does not work as the power button of the remote controller is off.
 4. To prevent breaker off due to the rush of starting current, systematize other home appliances not to turn on at the same time.

4-6 PIPE FORMING
 Place the drain hose below the refrigerant piping.
 Make sure that the drain hose is not heated or snaked.
 Do not pull the hose to apply the tape.
 When the drain hose passes the room, be sure to wrap insulation material (obtainable at a store) around it.
 Wrap the left tape around the pipe and the drain hose, then put the pipe in the back space of the indoor unit.

CAUTION
 Be careful not to make mis-wiring. Firmly tighten the terminal screws to prevent them from loosening. After tightening, pull the wires lightly to confirm that they do not move. If the connecting wire is incorrectly connected to the terminal block, the unit does not operate normally. If an earth is incorrect, it may cause an electric shock.

FOR REAR, RIGHT OR DOWNWARD PIPING
 Pipe arrangement: Put the refrigerant piping and the drain hose together, then apply piping tape to them.
 Be careful drain hose is not heated. Firmly apply piping tape from the end.
 Cut off in case of right piping. Cut off in case of downward piping.

FOR LEFT OR LEFT-REAR PIPING
 Pipe arrangement: Put the refrigerant piping and the drain hose together, then apply felt tape to them.
 Be careful drain hose is not heated. Cut off in case of left piping. Use a bandage stopper at the end of felt tape.

REATTACHING DRAIN HOSE
 Be sure to reattach the drain hose and the drain cap in case of left or left-rear piping. Otherwise, it could cause drops of water to drip down from the drain hose.

1. Pull out the drain cap at the rear right of the indoor unit.
 Hold the convex section at the end and pull the drain cap.

2. Pull out the drain hose at the rear left of the indoor unit.
 Hold the claw marked by the arrow and pull out the drain hose forward.

6-5 TEST RUN
 MSH type
 Before performing the test run, check for any wrong wiring. Wrong wiring prevents normal operation or results in blown fuse disabling operation. The test run can be started by pressing EMERGENCY OPERATION switch. When the EMERGENCY OPERATION switch is once pressed, the unit will start the test run (continuous operation) for 30 minutes. A thermostat does not work during this time. After 30 minutes the unit will start the EMERGENCY OPERATION at a fixed temperature setting of 24°C in COOL MODE. Perform test run in the following procedure.

6-6 EXPLANATION TO THE CUSTOMER
 Using the OPERATING INSTRUCTIONS, explain the following to the customer, how to control temperature, how to remove the air filters, how to remove or put the remote controller in the remote controller holder, how to clean, precautions for operation, etc. Recommend the customer to read the OPERATING INSTRUCTIONS carefully.

7. FOR MOVEMENT AND MAINTENANCE

7-1 REMOVING AND REINSTALLING THE FRONT PANEL
FRONT PANEL REMOVAL
 Release the hooks.
 Remove the screw caps.
 Push the bottom.
FRONT PANEL REINSTALLATION
 Point the horizontal vane downward.
 Push the bottom.
 Attach the bottom of the front panel under the horizontal vane.
 Fit in the top of the front panel.
 Push the section of the front panel marked by the arrow and fit the panel into the air conditioner.

7-2 REMOVING THE INDOOR UNIT
 Remove the bottom of the indoor unit from the installation plate.
 Remove the front panel. (See FRONT PANEL REMOVAL show above.)
 Insert flat screwdrivers into the square holes at the left and right bottom of the indoor unit and push them up. The bottom of the indoor unit goes down and the books are released.

7-3 GAS CHARGE
 Connect gas cylinder to the service port of stop valve (3-way).
 Execute air purge of the pipe (or hose) coming from refrigerant gas cylinder.
 Replenish specified amount of the refrigerant, while operating the air conditioner for cooling.
 Note:
 In case of adding refrigerant, comply with the quantity specified for the refrigerating cycle.
 Do not discharge the refrigerant into the atmosphere.
 Take care not to discharge refrigerant into the atmosphere during installation, reinstallation, or repairs to the refrigerant circuit.
 For additional charging, charge the refrigerant from liquid phase of the gas cylinder.
 If the refrigerant is charged from the gas phase, composition change may occur in the refrigerant inside the cylinder and the outdoor unit. In this case, ability of the refrigerating cycle decreases or normal operation can be impossible. However, charging the liquid refrigerant all at once may cause the compressor to be locked. Thus, charge the refrigerant slowly.
 To maintain the high pressure of the gas cylinder, warm the gas cylinder with warm water (under 40°C) during cold season. But never use naked fire or steam.

7-4 REMOVING THE INDOOR UNIT
 Remove the bottom of the indoor unit from the installation plate.
 Remove the front panel. (See FRONT PANEL REMOVAL show above.)
 Insert flat screwdrivers into the square holes at the left and right bottom of the indoor unit and push them up. The bottom of the indoor unit goes down and the books are released.

7-5 GAS CHARGE
 Connect gas cylinder to the service port of stop valve (3-way).
 Execute air purge of the pipe (or hose) coming from refrigerant gas cylinder.
 Replenish specified amount of the refrigerant, while operating the air conditioner for cooling.
 Note:
 In case of adding refrigerant, comply with the quantity specified for the refrigerating cycle.
 Do not discharge the refrigerant into the atmosphere.
 Take care not to discharge refrigerant into the atmosphere during installation, reinstallation, or repairs to the refrigerant circuit.
 For additional charging, charge the refrigerant from liquid phase of the gas cylinder.
 If the refrigerant is charged from the gas phase, composition change may occur in the refrigerant inside the cylinder and the outdoor unit. In this case, ability of the refrigerating cycle decreases or normal operation can be impossible. However, charging the liquid refrigerant all at once may cause the compressor to be locked. Thus, charge the refrigerant slowly.
 To maintain the high pressure of the gas cylinder, warm the gas cylinder with warm water (under 40°C) during cold season. But never use naked fire or steam.

7-6 EXPLANATION TO THE CUSTOMER
 Using the OPERATING INSTRUCTIONS, explain the following to the customer, how to control temperature, how to remove the air filters, how to remove or put the remote controller in the remote controller holder, how to clean, precautions for operation, etc. Recommend the customer to read the OPERATING INSTRUCTIONS carefully.

7-7 GAS CHARGE
 Connect gas cylinder to the service port of stop valve (3-way).
 Execute air purge of the pipe (or hose) coming from refrigerant gas cylinder.
 Replenish specified amount of the refrigerant, while operating the air conditioner for cooling.
 Note:
 In case of adding refrigerant, comply with the quantity specified for the refrigerating cycle.
 Do not discharge the refrigerant into the atmosphere.
 Take care not to discharge refrigerant into the atmosphere during installation, reinstallation, or repairs to the refrigerant circuit.
 For additional charging, charge the refrigerant from liquid phase of the gas cylinder.
 If the refrigerant is charged from the gas phase, composition change may occur in the refrigerant inside the cylinder and the outdoor unit. In this case, ability of the refrigerating cycle decreases or normal operation can be impossible. However, charging the liquid refrigerant all at once may cause the compressor to be locked. Thus, charge the refrigerant slowly.
 To maintain the high pressure of the gas cylinder, warm the gas cylinder with warm water (under 40°C) during cold season. But never use naked fire or steam.

7-8 EXPLANATION TO THE CUSTOMER
 Using the OPERATING INSTRUCTIONS, explain the following to the customer, how to control temperature, how to remove the air filters, how to remove or put the remote controller in the remote controller holder, how to clean, precautions for operation, etc. Recommend the customer to read the OPERATING INSTRUCTIONS carefully.

7-9 EXPLANATION TO THE CUSTOMER
 Using the OPERATING INSTRUCTIONS, explain the following to the customer, how to control temperature, how to remove the air filters, how to remove or put the remote controller in the remote controller holder, how to clean, precautions for operation, etc. Recommend the customer to read the OPERATING INSTRUCTIONS carefully.

7-10 EXPLANATION TO THE CUSTOMER
 Using the OPERATING INSTRUCTIONS, explain the following to the customer, how to control temperature, how to remove the air filters, how to remove or put the remote controller in the remote controller holder, how to clean, precautions for operation, etc. Recommend the customer to read the OPERATING INSTRUCTIONS carefully.

7-11 EXPLANATION TO THE CUSTOMER
 Using the OPERATING INSTRUCTIONS, explain the following to the customer, how to control temperature, how to remove the air filters, how to remove or put the remote controller in the remote controller holder, how to clean, precautions for operation, etc. Recommend the customer to read the OPERATING INSTRUCTIONS carefully.

7-12 EXPLANATION TO THE CUSTOMER
 Using the OPERATING INSTRUCTIONS, explain the following to the customer, how to control temperature, how to remove the air filters, how to remove or put the remote controller in the remote controller holder, how to clean, precautions for operation, etc. Recommend the customer to read the OPERATING INSTRUCTIONS carefully.

7-13 EXPLANATION TO THE CUSTOMER
 Using the OPERATING INSTRUCTIONS, explain the following to the customer, how to control temperature, how to remove the air filters, how to remove or put the remote controller in the remote controller holder, how to clean, precautions for operation, etc. Recommend the customer to read the OPERATING INSTRUCTIONS carefully.

7-14 EXPLANATION TO THE CUSTOMER
 Using the OPERATING INSTRUCTIONS, explain the following to the customer, how to control temperature, how to remove the air filters, how to remove or put the remote controller in the remote controller holder, how to clean, precautions for operation, etc. Recommend the customer to read the OPERATING INSTRUCTIONS carefully.

7-15 EXPLANATION TO THE CUSTOMER
 Using the OPERATING INSTRUCTIONS, explain the following to the customer, how to control temperature, how to remove the air filters, how to remove or put the remote controller in the remote controller holder, how to clean, precautions for operation, etc. Recommend the customer to read the OPERATING INSTRUCTIONS carefully.

7-16 EXPLANATION TO THE CUSTOMER
 Using the OPERATING INSTRUCTIONS, explain the following to the customer, how to control temperature, how to remove the air filters, how to remove or put the remote controller in the remote controller holder, how to clean, precautions for operation, etc. Recommend the customer to read the OPERATING INSTRUCTIONS carefully.

7-17 EXPLANATION TO THE CUSTOMER
 Using the OPERATING INSTRUCTIONS, explain the following to the customer, how to control temperature, how to remove the air filters, how to remove or put the remote controller in the remote controller holder, how to clean, precautions for operation, etc. Recommend the customer to read the OPERATING INSTRUCTIONS carefully.

7-18 EXPLANATION TO THE CUSTOMER
 Using the OPERATING INSTRUCTIONS, explain the following to the customer, how to control temperature, how to remove the air filters, how to remove or put the remote controller in the remote controller holder,