

# SERVICE MANUAL

## Series PLA Ceiling Cassettes

**R407C/R410A**

### Indoor unit [Model names]

PLA-RP35AA  
 PLA-RP50AA  
 PLA-RP60AA  
 PLA-RP71AA  
 PLA-RP100AA  
 PLA-RP125AA  
 PLA-RP140AA

### [Service Ref.]

PLA-RP35AA.UK  
 PLA-RP50AA.UK  
 PLA-RP60AA.UK  
 PLA-RP71AA.UK  
 PLA-RP100AA.UK  
 PLA-RP125AA.UK  
 PLA-RP140AA.UK

### NOTE:


- This manual describes only service data of the indoor units.

## Series PLH

**R407C**

PLH-P35AAH  
 PLH-P50AAH  
 PLH-P60AAH  
 PLH-P71AAH  
 PLH-P100AAH  
 PLH-P125AAH  
 PLH-P140AAH


PLH-P35AAH.UK  
 PLH-P50AAH.UK  
 PLH-P60AAH.UK  
 PLH-P71AAH.UK  
 PLH-P100AAH.UK  
 PLH-P125AAH.UK  
 PLH-P140AAH.UK



INDOOR UNIT



WIRELESS REMOTE  
CONTROLLER



WIRED REMOTE  
CONTROLLER

## CONTENTS

1. REFERENCE MANUAL .....	2
2. SAFETY PRECAUTION .....	2
3. PART NAMES AND FUNCTIONS .....	6
4. SPECIFICATIONS .....	9
5. NOISE CRITERION CURVES .....	14
6. OUTLINES AND DIMENSIONS .....	16
7. WIRING DIAGRAM .....	17
8. REFRIGERANT SYSTEM DIAGRAM .....	18
9. TROUBLESHOOTING .....	19
10. DISASSEMBLY PROCEDURE .....	35
11. PARTS LIST .....	38

# 1 REFERENCE MANUAL

## 1-1. OUTDOOR UNIT'S SERVICE MANUAL

Service Ref.	Service Manual No.
PUHZ-RP35/50/60/71/100/125/140VHA PUHZ-RP100/125/140YHA	OC334
PUHZ-RP200/250YHA	OC338
PU(H)-P-VGAA.UK PU(H)-P-YGAA.UK	OC336
SUZ-KA-VA.TH	OC322
MXZ-8A140VA MXZ-8A140VA <sub>1</sub>	OC316

## 1-2. TECHNICAL DATA BOOK

Series (Outdoor unit)	Manual No.
PUHZ-RP-VHA(-A) PUHZ-RP-YHA(-A)	OCS01
PU(H)-P-VGAA.UK PU(H)-P-YGAA.UK	OCS02

# 2 SAFETY PRECAUTION

## CAUTIONS RELATED TO NEW REFRIGERANT

Cautions for units utilising refrigerant R407C

### Do not use the existing refrigerant piping.

The old refrigerant and lubricant in the existing piping contains a large amount of chlorine which may cause the lubricant deterioration of the new unit.

### Use "low residual oil piping"

If there is a large amount of residual oil (hydraulic oil, etc.) inside the piping and joints, deterioration of the lubricant will result.

### Store the piping to be used during installation indoors with keep both ends sealed until just before brazing. (Store elbows and other joints in a plastic bag.)

If dust, dirt, or water enters the refrigerant cycle, deterioration of the oil and compressor trouble may result.

### Use ESTER , ETHER or HAB as the lubricant to coat flares and flange connection parts.

If large amount of mineral oil enter, that can cause deterioration of refrigerant oil etc.

### Use liquid refrigerant to charge the system.

If gas refrigerant is used to seal the system, the composition of the refrigerant in the cylinder will change and performance may drop.

### Do not use a refrigerant other than R407C.

If another refrigerant (R22, etc.) is used, the chlorine in the refrigerant may cause the lubricant deterioration.

### Use a vacuum pump with a reverse flow check valve.

The vacuum pump oil may flow back into the refrigerant cycle and cause the lubricant deterioration.

### Ventilate the room if refrigerant leaks during operation. If refrigerant comes into contact with a flame, poisonous gases will be released.


## [1] Cautions for service

- After recovering the all refrigerant in the unit, proceed to working.
- Do not release refrigerant in the air.
- After completing the repair service, recharge the cycle with the specified amount of liquid refrigerant.

## [2] Refrigerant recharging

### (1) Refrigerant recharging process

- ①Direct charging from the cylinder.
    - R407C cylinder are available on the market has a syphon pipe.
    - Leave the syphon pipe cylinder standing and recharge it.
- (By liquid refrigerant)



### (2) Recharge in refrigerant leakage case

- After recovering the all refrigerant in the unit, proceed to working.
- Do not release the refrigerant in the air.
- After completing the repair service, recharge the cycle with the specified amount of liquid refrigerant.

## [3] Service tools

Use the below service tools as exclusive tools for R407C refrigerant.

No.	Tool name	Specifications
①	Gauge manifold	·Only for R407C.
		·Use the existing fitting SPECIFICATIONS. (UNF7/16)
		·Use high-tension side pressure of 3.43MPa·G or over.
②	Charge hose	·Only for R407C.
		·Use pressure performance of 5.10MPa·G or over.
③	Electronic scale	
④	Gas leak detector	·Use the detector for R134a or R407C.
⑤	Adapter for reverse flow check.	·Attach on vacuum pump.
⑥	Refrigerant charge base.	
⑦	Refrigerant cylinder.	·For R407C    ·Top of cylinder (Brown)
		·Cylinder with syphon
⑧	Refrigerant recovery equipment.	

## CAUTIONS RELATED TO NEW REFRIGERANT

### Cautions for units utilising refrigerant R410A

#### Use new refrigerant pipes.

In case of using the existing pipes for R22, be careful with the followings.

- For RP100, 125 and 140, be sure to perform replacement operation before test run.
- Change flare nut to the one provided with this product. Use a newly flared pipe.
- Avoid using thin pipes.

**Make sure that the inside and outside of refrigerant piping is clean and it has no contamination such as sulfur hazardous for use, oxides, dirt, shaving particles, etc.**  
**In addition, use pipes with specified thickness.**

Contamination inside refrigerant piping can cause deterioration of refrigerant oil etc.

**Store the piping to be used during installation indoors and keep both ends of the piping sealed until just before brazing. (Leave elbow joints, etc. in their packaging.)**

If dirt, dust or moisture enter into refrigerant cycle, that can cause deterioration of refrigerant oil or malfunction of compressor.

**Use ester oil, ether oil or alkylbenzene oil (small amount) as the refrigerant oil applied to flares and flange connections.**

If large amount of mineral oil enter, that can cause deterioration of refrigerant oil etc.

#### Charge refrigerant from liquid phase of gas cylinder.

If the refrigerant is charged from gas phase, composition change may occur in refrigerant and the efficiency will be lowered.

#### Do not use refrigerant other than R410A.

If other refrigerant (R22 etc.) is used, chlorine in refrigerant can cause deterioration of refrigerant oil etc.

#### Use a vacuum pump with a reverse flow check valve.

Vacuum pump oil may flow back into refrigerant cycle and that can cause deterioration of refrigerant oil etc.

#### Use the following tools specifically designed for use with R410A refrigerant.

The following tools are necessary to use R410A refrigerant.

Tools for R410A	
Gauge manifold	Flare tool
Charge hose	Size adjustment gauge
Gas leak detector	Vacuum pump adaptor
Torque wrench	Electronic refrigerant charging scale

#### Keep the tools with care.

If dirt, dust or moisture enter into refrigerant cycle, that can cause deterioration of refrigerant oil or malfunction of compressor.

#### Do not use a charging cylinder.

If a charging cylinder is used, the composition of refrigerant will change and the efficiency will be lowered.

**Ventilate the room if refrigerant leaks during operation. If refrigerant comes into contact with a flame, poisonous gases will be released.**


## [1] Cautions for service

- (1) Perform service after collecting the refrigerant left in unit completely.
- (2) Do not release refrigerant in the air.
- (3) After completing service, charge the cycle with specified amount of refrigerant.
- (4) When performing service, install a filter drier simultaneously.  
Be sure to use a filter drier for new refrigerant.

## [2] Additional refrigerant charge

### When charging directly from cylinder

- Check that cylinder for R410A on the market is syphon type.
- Charging should be performed with the cylinder of syphon stood vertically. (Refrigerant is charged from liquid phase.)




### [3] Service tools

Use the below service tools as exclusive tools for R410A refrigerant.

No.		Specifications
①	Gauge manifold	·Only for R410A
		·Use the existing fitting specifications. (UNF1/2)
		·Use high-tension side pressure of 5.3MPa·G or over.
②	Charge hose	·Only for R410A
		·Use pressure performance of 5.09MPa·G or over.
③	Electronic scale	—
④	Gas leak detector	·Use the detector for R134a, R407C or R410A.
⑤	Adaptor for reverse flow check	·Attach on vacuum pump.
⑥	Refrigerant charge base	—
⑦	Refrigerant cylinder	·Only for R410A    Top of cylinder (Pink)
		Cylinder with syphon
⑧	Refrigerant recovery equipment	—


### ● Indoor Unit




### ● Wired remote controller

On the controls are set, the same operation mode can be repeated by simply pressing the ON/OFF button.

### ● Operation buttons




## ● Display



## Caution

- Only the Power on indicator lights when the unit is stopped and power supplied to the unit.
- If you press a button for a feature that is not installed at the indoor unit, the remote controller will display the “Not Available” message.  
If you are using the remote controller to drive multiple indoor units, this message will appear only if the feature is not present at the parent unit.
- When power is turned ON for the first time, it is normal that “PLEASE WAIT” is displayed on the room temperature indication (For max. 2minutes). Please wait until this “PLEASE WAIT” indication disappear then start the operation.

## ● Wireless remote controller





Service Ref.			PLA-RP35AA.UK	
INDOOR UNIT	Mode		Cooling	Heating
	Power supply(phase, cycle, voltage)		Single phase, 50Hz, 230V	
	Input	kW	0.16	0.16
	Running current	A	0.79	0.79
	Starting current	A	1.0	1.0
	External finish (Panel)		Munsell 0.70Y 8.59/0.97	
	Heat exchanger		Plate fin coil	
	Fan	Fan(drive) × No.	Turbo fan (direct) × 1	
		Fan motor output	0.070	
		Airflow(Low-Medium2-Medium1-High)	11-12-13-14(390-425-460-495)	
		External static pressure	0(direct blow)	
	Booster heater		—	
	Operation control & Thermostat		Remote controller & built-in	
	Noise level(Low-Medium2-Medium1-High)		27-28-29-31	
	Unit drain pipe I.D.		32 (1-1/4)	
	Dimensions	W	UNIT : 840 (33-1/16)	PANEL : 950 (37-3/8)
		D	UNIT : 840 (33-1/16)	PANEL : 950 (37-3/8)
		H	UNIT : 258 (10-3/16)	PANEL : 30 (1-3/16)
	Weight		UNIT : 24 (53)	PANEL : 5 (11)

Service Ref.			PLA-RP50AA.UK	
INDOOR UNIT	Mode		Cooling	Heating
	Power supply(phase, cycle, voltage)		Single phase, 50Hz, 230V	
	Input	kW	0.16	0.16
	Running current	A	0.79	0.79
	Starting current	A	1.0	1.0
	External finish (Panel)		Munsell 0.70Y 8.59/0.97	
	Heat exchanger		Plate fin coil	
	Fan	Fan(drive) × No.	Turbo fan (direct) × 1	
		Fan motor output	0.070	
		Airflow(Low-Medium2-Medium1-High)	14-15-16-18(495-530-565-635)	
		External static pressure	0(direct blow)	
	Booster heater		—	
	Operation control & Thermostat		Remote controller & built-in	
	Noise level(Low-Medium2-Medium1-High)		28-29-31-33	
	Unit drain pipe I.D.		32(1-1/4)	
	Dimensions	W	UNIT : 840 (33-1/16)	PANEL : 950 (37-3/8)
		D	UNIT : 840 (33-1/16)	PANEL : 950 (37-3/8)
		H	UNIT : 258 (10-3/16)	PANEL : 30 (1-3/16)
	Weight		UNIT : 24 (53)	PANEL : 5 (11)

Service Ref.			PLA-RP60AA.UK	
INDOOR UNIT	Mode		Cooling	Heating
	Power supply(phase, cycle, voltage)		Single phase, 50Hz, 230V	
	Input	kW	0.16	0.16
	Running current	A	0.79	0.79
	Starting current	A	1.0	1.0
	External finish (Panel)		Munsell 0.70Y 8.59/0.97	
	Heat exchanger		Plate fin coil	
	Fan	Fan(drive) × No.	Turbo fan (direct) × 1	
		Fan motor output	0.070	
		Airflow(Low-Medium2-Medium1-High)	14-15-16-18(495-530-565-635)	
		External static pressure	0(direct blow)	
	Booster heater		—	
	Operation control & Thermostat		Remote controller & built-in	
	Noise level(Low-Medium2-Medium1-High)		28-29-31-33	
	Unit drain pipe I.D.		32(1-1/4)	
	Dimensions	W	UNIT : 840 (33-1/16)	PANEL : 950 (37-3/8)
		D	UNIT : 840 (33-1/16)	PANEL : 950 (37-3/8)
		H	UNIT : 258 (10-3/16)	PANEL : 30 (1-3/16)
	Weight		UNIT : 24 (53)	PANEL : 5 (11)

INDOOR UNIT	Service Ref'			PLA-RP71AA.UK			
	Mode			Cooling		Heating	
	Power supply(phase, cycle, voltage)			Single phase, 50Hz, 230V			
	Input		kW	0.16		0.16	
	Running current		A	0.79		0.79	
	Starting current		A	1.0		1.0	
	External finish (Panel)			Munsell 0.70Y 8.59/0.97			
	Heat exchanger			Plate fin coil			
	Fan	Fan(drive) × No.		Turbo fan (direct) × 1			
		Fan motor output		kW	0.070		
		Airflow(Low-Medium2-Medium1-High)		m³/min(CFM)	15-16-18-20(530-565-635-705)		
		External static pressure		Pa(mmAq)	0(direct blow)		
	Booster heater		kW	—			
	Operation control & Thermostat			Remote controller & built-in			
	Noise level(Low-Medium2-Medium1-High)		dB	28-30-32-34			
	Unit drain pipe I.D.		mm(in.)	32(1-1/4)			
Dimensions		W	mm(in.)	UNIT : 840 (33-1/16)		PANEL: 950 (37-3/8)	
		D	mm(in.)	UNIT : 840 (33-1/16)		PANEL: 950 (37-3/8)	
		H	mm(in.)	UNIT : 258 (10-3/16)		PANEL: 30 (1-3/16)	
Weight		kg(lbs)	UNIT : 24 (53)		PANEL: 5 (11)		

INDOOR UNIT	Service Ref.			PLA-RP100AA.UK				
	Mode			Cooling		Heating		
	Power supply(phase, cycle, voltage)			Single phase, 50Hz, 230V				
	Input		kW	0.25		0.25		
	Running current		A	1.25		1.25		
	Starting current		A	2.0		2.0		
	External finish (Panel)			Munsell 0.70Y 8.59/0.97				
	Heat exchanger			Plate fin coil				
	Fan	Fan(drive) × No.		Turbo fan (direct) × 1				
		Fan motor output		kW	0.120			
		Airflow(Low-Medium2-Medium1-High)		m³/min(CFM)	20-23-26-28(705-810-920-980)			
		External static pressure		Pa(mmAq)	0(direct blow)			
	Booster heater		kW	—				
	Operation control & Thermostat			Remote controller & built-in				
	Noise level(Low-Medium2-Medium1-High)		dB	33-36-39-41				
Unit drain pipe I.D.		mm(in.)	32(1-1/4)					
Dimensions		W	mm(in.)	UNIT : 840 (33-1/16)			PANEL : 950 (37-3/8)	
		D	mm(in.)	UNIT : 840 (33-1/16)			PANEL : 950 (37-3/8)	
		H	mm(in.)	UNIT : 298 (11-3/4)			PANEL : 30 (1-3/16)	
Weight		kg(lbs)	UNIT : 30 (66)		PANEL : 5 (11)			

INDOOR UNIT	Service Ref.			PLA-RP125AA.UK				
	Mode			Cooling		Heating		
	Power supply(phase, cycle, voltage)			Single phase, 50Hz, 230V				
	Input		kW	0.33		0.33		
	Running current		A	1.64		1.64		
	Starting current		A	2.0		2.0		
	External finish (Panel)			Munsell 0.70Y 8.59/0.97				
	Heat exchanger			Plate fin coil				
	Fan	Fan(drive) × No.		Turbo fan (direct) × 1				
		Fan motor output		kW	0.120			
		Airflow(Low-Medium2-Medium1-High)		m³/min(CFM)	22-25-28-30(775-880-990-1,060)			
		External static pressure		Pa(mmAq)	0(direct blow)			
	Booster heater		kW	—				
	Operation control & Thermostat			Remote controller & built-in				
	Noise level(Low-Medium2-Medium1-High)		dB	37-40-43-45				
Unit drain pipe I.D.		mm(in.)	32(1-1/4)					
Dimensions		W	mm(in.)	UNIT : 840 (33-1/16) PANEL : 950 (37-3/8)				
		D	mm(in.)	UNIT : 840 (33-1/16) PANEL : 950 (37-3/8)				
		H	mm(in.)	UNIT : 298 (11-3/4) PANEL : 30 (1-3/16)				
Weight		kg(lbs)	UNIT : 32 (71) PANEL : 5 (11)					

Service Ref.				PLA-RP140AA.UK	
INDOOR UNIT	Mode			Cooling	Heating
	Power supply(phase, cycle, voltage)			Single phase, 50Hz, 230V	
	Input	kW		0.33	0.33
	Running current	A		1.64	1.64
	Starting current	A		2.0	2.0
	External finish (Panel)			Munsell 0.70Y 8.59/0.97	
	Heat exchanger			Plate fin coil	
	Fan	Fan(drive) x No.		Turbo fan (direct) × 1	
		Fan motor output		0.120	
		Airflow(Low-Medium2-Medium1-High)		22-25-28-30(775-880-990-1,060)	
		External static pressure		0(direct blow)	
	Booster heater		kW	-	
	Operation control & Thermostat			Remote controller & built-in	
	Noise level(Low-Medium2-Medium1-High)		dB	37-40-43-45	
	Unit drain pipe I.D.		mm(in.)	32(1-1/4)	
	Dimensions	W	mm(in.)	UNIT : 840 (33-1/16) PANEL : 950 (37-3/8)	
		D	mm(in.)	UNIT : 840 (33-1/16) PANEL : 950 (37-3/8)	
		H	mm(in.)	UNIT : 298 (11-3/4) PANEL : 30 (1-3/16)	
	Weight		kg(lbs)	UNIT : 32 (71) PANEL : 5 (11)	

Service Ref.				PLH-P35AAH.UK	
INDOOR UNIT	Mode			Cooling	Heating
	Power supply(phase, cycle, voltage)			Single phase, 50Hz, 230V	
	Input ※1	kW		0.16	0.16<1.29>
	Running current ※1	A		0.79	0.75<5.61>
	Starting current ※1	A		1.0	1.0<5.61>
	External finish			Munsell 0.70Y 8.59/0.97	
	Heat exchanger			Plate fin coil	
	Fan	Fan(drive) × No.		Turbo fan (direct) × 1	
		Fan motor output		0.070	
		Airflow(Low-Medium2-Medium1-High)		11-12-13-14(390-425-460-495)	
		External static pressure		0(direct blow)	
	Booster heater ※1		kW	<1.29>	
	Operation control & Thermostat			Remote controller & built-in	
	Noise level(Low-Medium2-Medium1-High)		dB	27-28-29-31	
	Unit drain pipe I.D.		mm(in.)	32(1-1/4)	
	Dimensions	W	mm(in.)	UNIT : 840 (33-1/16) PANEL : 950 (37-3/8)	
		D	mm(in.)	UNIT : 840 (33-1/16) PANEL : 950 (37-3/8)	
		H	mm(in.)	UNIT : 258 (10-3/16) PANEL : 30 (1-3/16)	
	Weight		kg(lbs)	UNIT : 26 (57) PANEL : 5 (11)	

Service Ref.				PLH-P50AAH.UK	
INDOOR UNIT	Mode			Cooling	Heating
	Power supply(phase, cycle, voltage)			Single phase, 50Hz, 230V	
	Input ※1	kW		0.16	0.16<1.29>
	Running current ※1	A		0.79	0.75<5.61>
	Starting current ※1	A		1.0	1.0<5.61>
	External finish			Munsell 0.70Y 8.59/0.97	
	Heat exchanger			Plate fin coil	
	Fan	Fan(drive) × No.		Turbo fan (direct) × 1	
		Fan motor output		0.070	
		Airflow(Low-Medium2-Medium1-High)		14-15-16-18(495-530-565-635)	
		External static pressure		0(direct blow)	
	Booster heater ※1		kW	<1.29>	
	Operation control & Thermostat			Remote controller & built-in	
	Noise level(Low-Medium2-Medium1-High)		dB	27-28-29-31	
	Unit drain pipe I.D.		mm(in.)	32(1-1/4)	
	Dimensions	W	mm(in.)	UNIT : 840 (33-1/16) PANEL : 950 (37-3/8)	
		D	mm(in.)	UNIT : 840 (33-1/16) PANEL : 950 (37-3/8)	
		H	mm(in.)	UNIT : 258 (10-3/16) PANEL : 30 (1-3/16)	
	Weight		kg(lbs)	UNIT : 26 (57) PANEL : 5 (11)	

※1 : < > Shows the only booster heater rating.

Service Ref.			PLH-P60AAH.UK	
INDOOR UNIT	Mode		Cooling	Heating
	Power supply(phase, cycle, voltage)		Single phase, 50Hz, 230V	
	Input	*1 kW	0.16	0.16<1.93>
	Running current	*1 A	0.79	0.79<8.39>
	Starting current	*1 A	1.0	1.0<8.39>
	External finish		Munsell 0.70Y 8.59/0.97	
	Heat exchanger		Plate fin coil	
	Fan	Fan(drive) × No.	Turbo fan (direct) × 1	
		Fan motor output	0.070	
		Airflow(Low-Medium2-Medium1-High)	14-15-16-18(495-530-565-635)	
		External static pressure	0(direct blow)	
	Booster heater *1		<1.93>	
	Operation control & Thermostat		Remote controller & built-in	
	Noise level(Low-Medium2-Medium1-High)		28-29-31-33	
	Unit drain pipe I.D.		32(1-1/4)	
	Dimensions	W	UNIT : 840 (33-1/16)	PANEL : 950 (37-3/8)
		D	UNIT : 840 (33-1/16)	PANEL : 950 (37-3/8)
		H	UNIT : 258 (10-3/16)	PANEL : 30 (1-3/16)
	Weight		UNIT : 26 (57)	PANEL : 5 (11)

Service Ref.			PLH-P71AAH.UK	
INDOOR UNIT	Mode		Cooling	Heating
	Power supply(phase, cycle, voltage)		Single phase, 50Hz, 230V	
	Input	*1 kW	0.16	0.16<1.93>
	Running current	*1 A	0.79	0.79<8.39>
	Starting current	*1 A	1.0	1.0<8.39>
	External finish		Munsell 0.70Y 8.59/0.97	
	Heat exchanger		Plate fin coil	
	Fan	Fan(drive) × No.	Turbo fan (direct) × 1	
		Fan motor output	0.070	
		Airflow(Low-Medium2-Medium1-High)	15-16-18-20(530-565-635-705)	
		External static pressure	0(direct blow)	
	Booster heater *1		-	
	Operation control & Thermostat		Remote controller & built-in	
	Noise level(Low-Medium2-Medium1-High)		28-30-32-34	
	Unit drain pipe I.D.		32(1-1/4)	
	Dimensions	W	UNIT : 840 (33-1/16)	PANEL : 950 (37-3/8)
		D	UNIT : 840 (33-1/16)	PANEL : 950 (37-3/8)
		H	UNIT : 258 (10-3/16)	PANEL : 30 (1-3/16)
	Weight		UNIT : 26 (57)	PANEL : 5 (11)

Service Ref.			PLH-P100AAH.UK	
INDOOR UNIT	Mode		Cooling	Heating
	Power supply(phase, cycle, voltage)		Single phase, 50Hz, 230V	
	Input	*1 kW	0.25	0.25<2.39>
	Running current	*1 A	1.25	1.25<10.39>
	Starting current	*1 A	2.0	2.0<10.39>
	External finish		Munsell 0.70Y 8.59/0.97	
	Heat exchanger		Plate fin coil	
	Fan	Fan(drive) × No.	Turbo fan (direct) × 1	
		Fan motor output	0.120	
		Airflow(Low-Medium2-Medium1-High)	20-23-26-28(705-810-920-980)	
		External static pressure	0(direct blow)	
	Booster heater *1		<2.39>	
	Operation control & Thermostat		Remote controller & built-in	
	Noise level(Low-Medium2-Medium1-High)		33-36-39-41	
	Unit drain pipe I.D.		32(1-1/4)	
	Dimensions	W	UNIT : 840 (33-1/16)	PANEL : 950 (37-3/8)
		D	UNIT : 840 (33-1/16)	PANEL : 950 (37-3/8)
		H	UNIT : 298 (11-3/4)	PANEL : 30 (1-3/16)
	Weight		UNIT : 32 (71)	PANEL : 5 (11)


\*1 : < > Shows the only booster heater rating.

Service Ref.				PLH-P125AAH.UK	
INDOOR UNIT	Mode			Cooling	Heating
	Power supply(phase, cycle, voltage)			Single phase, 50Hz, 230V	
	Input	※1	kW	0.33	0.33<2.76>
	Running current	※1	A	1.64	1.64<12.00>
	Starting current	※1	A	2.0	2.0<12.00>
	External finish			Munsell 0.70Y 8.59/0.97	
	Heat exchanger			Plate fin coil	
	Fan	Fan(drive) × No.		Turbo fan (direct) × 1	
		Fan motor output		0.120	
		Airflow(Low-Medium2-Medium1-High)		22-25-28-30(775-880-990-1,060)	
		External static pressure		0(direct blow)	
	Booster heater		※1	kW	<2.76>
	Operation control & Thermostat			Remote controller & built-in	
	Noise level(Low-Medium2-Medium1-High)			dB	
	Unit drain pipe I.D.			mm(in.)	
	Dimensions	W	mm(in.)	UNIT : 840 (33-1/16) PANEL : 950 (37-3/8)	
		D	mm(in.)	UNIT : 840 (33-1/16) PANEL : 950 (37-3/8)	
		H	mm(in.)	UNIT : 298 (11-3/4) PANEL : 30 (1-3/16)	
	Weight			kg(lbs)	
				UNIT : 34 (75) PANEL : 5 (11)	

Service Ref.				PLH-P140AAH.UK	
INDOOR UNIT	Mode			Cooling	Heating
	Power supply(phase, cycle, voltage)			Single phase, 50Hz, 230V	
	Input	※1	kW	0.33	0.33<2.76>
	Running current	※1	A	1.64	1.64<12.00>
	Starting current	※1	A	2.0	2.0<12.00>
	External finish			Munsell 0.70Y 8.59/0.97	
	Heat exchanger			Plate fin coil	
	Fan	Fan(drive) × No.		Turbo fan (direct) × 1	
		Fan motor output		0.120	
		Airflow(Low-Medium2-Medium1-High)		22-25-28-30(775-880-990-1,060)	
		External static pressure		0(direct blow)	
	Booster heater		※1	kW	<2.76>
	Operation control & Thermostat			Remote controller & built-in	
	Noise level(Low-Medium2-Medium1-High)			dB	
	Unit drain pipe I.D.			mm(in.)	
	Dimensions	W	mm(in.)	UNIT : 840 (33-1/16) PANEL : 950 (37-3/8)	
		D	mm(in.)	UNIT : 840 (33-1/16) PANEL : 950 (37-3/8)	
		H	mm(in.)	UNIT : 298 (11-3/4) PANEL : 30 (1-3/16)	
	Weight			kg(lbs)	
				UNIT : 34 (75) PANEL : 5 (11)	


PLA-RP35AA.UK  
PLH-P35AAH.UK

NOTCH	SPL(dB)	LINE
High	31	○—○
Medium1	29	△—△
Medium2	28	●—●
Low	27	▲—▲




PLA-RP50AA.UK  
PLA-RP60AA.UK  
PLH-P50AAH.UK  
PLH-P60AAH.UK

NOTCH	SPL(dB)	LINE
High	33	○—○
Medium1	31	△—△
Medium2	29	●—●
Low	28	▲—▲




PLA-RP71AA.UK  
PLH-P71AAH.UK

NOTCH	SPL(dB)	LINE
High	34	○—○
Medium1	32	△—△
Medium2	30	●—●
Low	28	▲—▲




PLA-RP100AA.UK  
PLH-P100AAH.UK

NOTCH	SPL(dB)	LINE
High	41	○—○
Medium1	39	△—△
Medium2	36	●—●
Low	33	▲—▲





**PLA-RP125AA.UK**  
**PLH-P125AAH.UK**

NOTCH	SPL(dB)	LINE
High	45	○—○
Medium1	43	△—△
Medium2	40	●—●
Low	37	▲—▲



**PLA-RP140AA.UK**  
**PLH-P140AAH.UK**


NOTCH	SPL(dB)	LINE
High	45	○—○
Medium1	43	△—△
Medium2	40	●—●
Low	37	▲—▲





## INDOOR UNIT

Unit : mm





PLA-RP35AA.UK PLA-RP50AA.UK PLA-RP60AA.UK PLA-RP71AA.UK  
 PLA-RP100AA.UK PLA-RP125AA.UK PLA-RP140AA.UK  
 PLH-P35AAH.UK PLH-P50AAH.UK PLH-P60AAH.UK PLH-P71AAH.UK  
 PLH-P100AAH.UK PLH-P125AAH.UK PLH-P140AAH.UK



Detail drawing of fresh air intake



A (WIRELESS PANEL)



Use the current nuts meeting the pipe size of the outdoor unit.

Available pipe size

	RP35, 50	RP60	RP71	RP100, 125, 140	P35,50,60,71	P100, 125, 140
① LIQUID SIDE	$\phi 6.35 \bigcirc$	$\phi 6.35$	—	—	—	—
	$\phi 9.52$	$\phi 9.52 \bigcirc$	$\phi 9.52 \bigcirc$	$\phi 9.52 \bigcirc$	$\phi 9.52 \bigcirc$	$\phi 9.52 \bigcirc$
② GAS SIDE	$\phi 12.7 \bigcirc$	—	—	—	—	—
	$\phi 15.88$	$\phi 15.88 \bigcirc$	$\phi 15.88 \bigcirc$	$\phi 15.88 \bigcirc$	$\phi 15.88 \bigcirc$	—
	—	—	—	$\phi 19.05$	—	$\phi 19.05 \bigcirc$

 $\bigcirc$  Factory flare nut attachment to the heat-exchanger.


Models	A	B	C
PLA-RP35,50,60,71AA PLH-P35,50,60,71AAH	241	258	80
PLA-RP100,125,140AA PLH-P100,125,140AAH	281	298	84



PLA-RP35AA.UK PLA-RP50AA.UK PLA-RP60AA.UK PLA-RP71AA.UK  
 PLA-RP100AA.UK PLA-RP125AA.UK PLA-RP140AA.UK  
 PLH-P35AAH.UK PLH-P50AAH.UK PLH-P60AAH.UK PLH-P71AAH.UK  
 PLH-P100AAH.UK PLH-P125AAH.UK PLH-P140AAH.UK

[LEGEND]

SYMBOL	NAME	SYMBOL	NAME	SYMBOL	NAME
P.B	INDOOR POWER BOARD	MF	FAN MOTOR	W.B	WIRELESS REMOTE CONTROLLER BOARD
I.B	INDOOR CONTROLLER BOARD	MV	VANE MOTOR	RU	RECEIVING UNIT
	FUSE(T6.3AL250V)	H2	DEW PREVENTION HEATER	BZ	BUZZER
	ZNR	DP	DRAIN-UP MACHINE	LED1	LED(RUN INDICATOR)
	BCR	DS	DRAIN SENSOR	LED2	LED(HOT ADJUST)
	CN2L	TB2	TERMINAL BLOCK (HEATER)*PLH-P.AAH models only or option for PLA-RP.AA models.	SW1	SWITCH(HEATING ON/OFF)
	CN32	TB4	TERMINAL BLOCK (INDOOR/OUTDOOR CONNECTING LINE)	SW2	SWITCH(COOLING ON/OFF)
	CN41	TB5, TB6	TERMINAL BLOCK(REMOTE CONTROLLER TRANSMISSION LINE)		
	CN51	TH1	ROOM TEMP.THERMISTOR (0°C/15kΩ,25°C/5.4kΩ DETECT)	HEATER	
	LED1	TH2	PIPE TEMP.THERMISTOR/LIQUID (0°C/15kΩ,25°C/5.4kΩ DETECT)	FS1	THERMAL FUSE(72°C, 16A)
	LED2	TH5	COND./EVA. TEMP. THERMISTOR (0°C/15kΩ,25°C/5.4kΩ DETECT)	FS2	THERMAL FUSE(104°C, 16A)
	LED3			H1	HEATER
	X1			26H	HEATER THERMAL SWITCH
	X4			88H	HEATER CONTACTOR
	SW1				
	SW2				
	SWE				
C	CAPACITOR(FAN MOTOR)	R.B	WIRED REMOTE CONTROLLER BOARD		



## NOTES:

1. Symbols used in wiring diagram above are, : Connector, : Terminal (block).
2. Indoor and outdoor connecting wires are made with polarities, make wiring matching terminal numbers (S1, S2, S3).
3. Since the outdoor side electric wiring may change be sure to check the outdoor unit electric wiring for servicing.
4. This diagram shows the wiring of Indoor and Outdoor connecting wires (specification of 230V), adopting superimposed system of power and signal.

※1 ; When work to supply power separately to Indoor and Outdoor unit was applied, refer to Fig1.  
 ※2 ; For power supply system of this unit, refer to the caution label located near this diagram.


Table 1

MODELS	SW1				
	Manufacture/Service				
PLA-RP. AA	1	2	3	4	5
	ON	OFF	ON	OFF	ON
PLH-P. AAH	1	2	3	4	5
	ON	OFF	ON	OFF	ON

Table 2

SW2			
MODELS	Manufacture/Service	MODELS	Manufacture/Service
PLA-RP35AA	1 2 3 4 5	PLA-RP100AA	1 2 3 4 5
PLH-P35AAH	ON OFF	PLH-P100AAH	ON OFF
PLA-RP50AA	1 2 3 4 5	PLA-RP125AA	1 2 3 4 5
PLH-P50AAH	ON OFF	PLH-P125AAH	ON OFF
PLA-RP60AA	1 2 3 4 5	PLA-RP140AA	1 2 3 4 5
PLH-P60AAH	ON OFF	PLH-P140AAH	ON OFF
PLA-RP71AA	1 2 3 4 5		
PLH-P71AAH	ON OFF		

PLA-RP35AA.UK PLA-RP50AA.UK PLA-RP60AA.UK PLA-RP71AA.UK  
 PLA-RP100AA.UK PLA-RP125AA.UK PLA-RP140AA.UK  
 PLH-P35AAH.UK PLH-P50AAH.UK PLH-P60AAH.UK PLH-P71AAH.UK  
 PLH-P100AAH.UK PLH-P125AAH.UK PLH-P140AAH.UK



### 9-1. TROUBLESHOOTING

#### <Error code display by self-diagnosis and actions to be taken for service (summary)>

Present and past error codes are logged and displayed on the wired remote controller or controller board of outdoor unit. Actions to be taken for service and the inferior phenomenon reoccurrence at field are summarized in the table below. Check the contents below before investigating details.

Unit conditions at service	Error code	Actions to be taken for service (summary)
The inferior phenomenon is reoccurring.	Displayed	Judge what is wrong and take a corrective action according to "SELF-DIAGNOSIS ACTION TABLE" (9-3).
	Not displayed	Identify the cause of the inferior phenomenon and take a corrective action according to "TROUBLESHOOTING BY INFERIOR PHENOMENA" (9-4).
The inferior phenomenon is not reoccurring.	Logged	①Consider the temporary defects such as the work of protection devices in the refrigerant circuit including compressor, poor connection of wiring, noise and etc. Re-check the symptom, and check the installation environment, refrigerant amount, weather when the inferior phenomenon occurred, and wiring related. ②Reset error code logs and restart the unit after finishing service. ③There is no abnormality in electrical components, controller boards, and remote controller.
	Not logged	①Recheck the abnormal symptom. ②Identify the cause of the inferior phenomenon and take a corrective action according to "TROUBLESHOOTING BY INFERIOR PHENOMENA" (9-4). ③Continue to operate unit for the time being if the cause is not ascertained. ④There is no abnormality in electrical components, controller boards, remote controller etc.

## 9-2. MALFUNCTION-DIAGNOSIS METHOD BY REMOTE CONTROLLER

### <In case of trouble during operation>



When a malfunction occurs to air conditioner, both indoor unit and outdoor unit will stop and operation lamp blinks to inform unusual stop.

### <Malfunction-diagnosis method at maintenance service>

#### [Procedure]

1. Press the CHECK button twice.

- "CHECK" lights, and refrigerant address "00" flashes.
- Check that the remote controller's display has stopped before continuing.

2. Press the temperature   buttons.


- Select the refrigerant address of the indoor unit for the self-diagnosis.  
Note: Set refrigerant address using the outdoor unit's DIP switch (SW1). (For more information, see the outdoor unit installation manual.)

3. Point the remote controller at the sensor on the indoor unit and press the HOUR button.

- If an air conditioner error occurs, the indoor unit's sensor emits an intermittent buzzer sound, the operation light flashes, and the error code is output.  
(It takes 3 seconds at most for error code to appear.)

4. Point the remote controller at the sensor on the indoor unit and press the ON/OFF button.


- The check mode is cancelled.




To be continued to the next page.

- Refer to the following tables for details on the check codes.

#### [Output pattern A]



#### [Output pattern B]



#### [Output pattern A] Errors detected by indoor unit

Wireless remote controller Beeper sounds/OPERATION INDICATOR lamp flashes (Number of times)	Wired remote controller ① Check code	Symptom	Remark
1	P1	Intake sensor error	
2	P2	Pipe (TH2) sensor error	
	P9	Pipe (TH5) sensor error	
3	E6, E7	Indoor/outdoor unit communication error	
4	P4	Drain sensor error	
5	P5	Drain pump error	
	PA	Forced compressor stop	
6	P6	Freezing/Overheating safeguard operation	
7	EE	Communication error between indoor and outdoor units	
8	P8	Pipe temperature error	
9	E4, E5	Remote controller signal receiving error	
10	–	–	
11	–	–	
12	Fb	Indoor unit control system error (memory error, etc.)	
–	E0, E3	Remote controller transmission error	
–	E1, E2	Remote controller control board error	

#### [Output pattern B] Errors detected by unit other than indoor unit (outdoor unit, etc.)

Wireless remote controller Beeper sounds/OPERATION INDICATOR lamp flashes (Number of times)	Wired remote controller ① Check code	Symptom	Remark
1	E9	Indoor/outdoor unit communication error (Transmitting error) (Outdoor unit)	For details, check the LED display of the outdoor controller board. As for outdoor unit, refer to outdoor unit's service manual.
2	UP	Compressor overcurrent interruption	
3	U3, U4	Open/short of outdoor unit thermistors	
4	UF	Compressor overcurrent interruption (When compressor locked)	
5	U2	Abnormal high discharging temperature/49C worked/insufficient refrigerant	
6	U1, Ud	Abnormal high pressure (63H worked)/Overheating safeguard operation	
7	U5	Abnormal temperature of heat sink	
8	U8	Outdoor unit fan safeguard stop	
9	U6	Compressor overcurrent interruption/Abnormal of power module	
10	U7	Abnormality of super heat due to low discharge temperature	
11	U9, UH	Abnormality such as overvoltage or voltage shortage and abnormal synchronous signal to main circuit/Current sensor error	
12	–	–	
13	–	–	
14	Others	Other errors (Refer to the technical manual for the outdoor unit.)	

\*1 If the beeper does not sound again after the initial two beeps to confirm the self-check start signal was received and the OPERATION INDICATOR lamp does not come on, there are no error records.

\*2 If the beeper sounds three times continuously "beep, beep, beep (0.4 + 0.4 + 0.4 sec.)" after the initial two beeps to confirm the self-check start signal was received, the specified refrigerant address is incorrect.

- On wireless remote controller
- ② The continuous buzzer sounds from receiving section of indoor unit.
- ③ Blink of operation lamp
- On wired remote controller
- ① Check code displayed in the LCD.

• If the unit cannot be operated properly after the above test run has been performed, refer to the following table to remove the cause.

Symptom			Cause
Wired remote controller		LED 1, 2 (PCB in outdoor unit)	
PLEASE WAIT	For about 2 minutes following power-on	After LED 1, 2 are lighted, LED 2 is turned off, then only LED 1 is lighted. (Correct operation)	• For about 2 minutes following power-on, operation of the remote controller is not possible due to system start-up. (Correct operation)
PLEASE WAIT → Error code	After about 2 minutes has expired following power-on	Only LED 1 is lighted. → LED 1, 2 blink.	• Connector for the outdoor unit's protection device is not connected. • Reverse or open phase wiring for the outdoor unit's power terminal block (L1, L2, L3)
Display messages do not appear even when operation switch is turned ON (operation lamp does not light up).		Only LED 1 is lighted. → LED 1 blinks twice, LED 2 blinks once.	• Incorrect wiring between indoor and outdoor units (incorrect polarity of S1, S2, S3) • Remote controller wire short

On the wireless remote controller with condition above, following phenomena takes place.

- No signals from the remote controller are accepted.
- OPE lamp is blinking.
- The buzzer makes a short piping sound.

**Note:**

**Operation is not possible for about 30 seconds after cancellation of function selection. (Correct operation)**

For description of each LED (LED1, 2, 3) provided on the indoor controller, refer to the following table.

LED1 (power for microcomputer)	Indicates whether control power is supplied. Make sure that this LED is always lit.
LED2 (power for remote controller)	Indicates whether power is supplied to the remote controller. This LED lights only in the case of the indoor unit which is connected to the outdoor unit refrigerant address "0".
LED3 (communication between indoor and outdoor units)	Indicates state of communication between the indoor and outdoor units. Make sure that this LED is always blinking.

### 9-3. SELF-DIAGNOSIS ACTION TABLE

Note: Refer to the manual of outdoor unit for the details of display such as F, U, and other E.

Error Code	Meaning of error code and detection method	Cause	Countermeasure
P1	<b>Abnormality of room temperature thermistor (TH1)</b> ① The unit is in three-minute resume prevention mode if short/open of thermistor is detected. Abnormal if the unit does not reset normally after three minutes. (The unit returns to normal operation, if it has normally reset.) ② Constantly detected during cooling, drying, and heating operation. Short: 90°C or more Open: -40°C or less	① Defective thermistor characteristics. ② Contact failure of connector (CN20) on the indoor controller board. (Insert failure) ③ Breaking of wire or contact failure of thermistor wiring. ④ Defective indoor controller board.	①—③ Check resistance value of thermistor. 0°C .....15.0kΩ 10°C .....9.6kΩ 20°C .....6.3kΩ 30°C .....4.3kΩ 40°C .....3.0kΩ If you put force on (draw or bend) the lead wire with measuring resistance value of thermistor breaking of wire or contact failure can be detected. ② Check contact failure of connector (CN20) on the indoor controller board. Refer to 9-7. Turn the power on again and check restart after inserting connector again. ④ Check room temperature display on remote controller. Replace indoor controller board if there is abnormal difference with actual room temperature.  Turn the power off, and on again to operate after check.
P2	<b>Abnormality of pipe temperature thermistor/Liquid (TH2)</b> ① The unit is in three-minute resume prevention mode if short/open of thermistor is detected. Abnormal if the unit does not reset normally after three minutes. (The unit returns to normal operation, if it has normally reset.) ② Constantly detected during cooling, drying, and heating (except defrosting) operation. Short: 90°C or more Open: -40°C or less	① Defective thermistor characteristics. ② Contact failure of connector (CN21) on the indoor controller board. (Insert failure) ③ Breaking of wire or contact failure of thermistor wiring. ④ Defective refrigerant circuit is causing thermistor temperature of 90°C or more or -40°C or less. ⑤ Defective indoor controller board.	①—③ Check resistance value of thermistor. For characteristics, refer to (P1) above. ② Check contact failure of connector (CN21) on the indoor controller board. Refer to 9-7. Turn the power on and check restart after inserting connector again. ④ Check pipe <liquid> temperature with remote controller in test run mode. If pipe <liquid> temperature is exclusively low (in cooling mode) or high (in heating mode), refrigerant circuit may have defective. ⑤ Check pipe <liquid> temperature with remote controller in test run mode. If there is exclusive difference with actual pipe <liquid> temperature, replace indoor controller board.  Turn the power off, and on again to operate after check.
P4	<b>Abnormality of drain sensor (DS)</b> ① Suspensive abnormality, if short/open of thermistor is detected for 30 seconds continuously. Turn off compressor and indoor fan. ② Short/open is detected for 30 seconds continuously during suspensive abnormality. (The unit returns to normal operation, if it has normally reset.) ③ Detect the following condition. • During cooling and drying operation. • In case that pipe <liquid> temperature - room temperature <-10deg (Except defrosting) • When pipe <liquid> temperature or room temperature is short/open temperature. • During drain pump operation.	① Defective thermistor characteristics ② Contact failure of connector (CN31) on the indoor controller board. (Insert failure). ③ Breaking of wire or contact failure of drain sensor wiring. ④ Defective indoor controller board.	①—③ Check resistance value of thermistor. 0°C .....6.0kΩ 10°C .....3.9kΩ 20°C .....2.6kΩ 30°C .....1.8kΩ 40°C .....1.3kΩ ② Check contact failure of connector (CN31) on the indoor controller board. Refer to 9-7. Turn the power on again and check restart after inserting connector again. ④ Replace indoor controller board if drain pump operates with the line of drain sensor connector CN31-① and ② is short-circuited, and abnormality reappears.  Turn the power off, and on again to operate after check.
P5	<b>Malfunction of drain pump (DP)</b> ① Suspensive abnormality, if thermistor of drain sensor is let heat itself and temperature rises slightly. Turn off compressor and indoor fan. ② Drain pump is abnormal if the condition above is detected during suspensive abnormality. ③ Constantly detected during drain pump operation.	① Malfunction of drain pump ② Defective drain Clogged drain pump Clogged drain pipe ③ Attached drop of water at the drain sensor • Drops of drain trickles from lead wire. • Clogged filter is causing wave of drain. ④ Defective indoor controller board.	① Check if drain-up machine works. ② Check drain function. ③ Check the setting of lead wire of drain sensor and check clogs of the filter. ④ Replace indoor controller board if drain pump operates with the line of drain sensor connector CN31-① and ② is short-circuited and abnormality reappears. Refer to 9-7.  Turn the power off, and on again to operate after check.

Error Code	Meaning of error code and detection method	Cause	Countermeasure
P6	<p><b>Freezing/overheating protection is working</b></p> <p>① Freezing protection (Cooling mode) The unit is in six-minute resume prevention mode if pipe &lt;liquid or condenser/evaporator&gt; temperature stays under -15°C for three minutes, three minutes after the compressor started. Abnormal if it stays under -15°C for three minutes again within 16 minutes after six-minute resume prevention mode. &lt;Frost prevention mode&gt; If pipe &lt;liquid or condenser-evaporator&gt; temperature is 2°C or below when 16 minutes has passed after compressor starts operating, unit will start operating in frost prevention mode which stops compressor operation. After that, when pipe &lt;liquid or condenser/evaporator&gt; temperature stays 10°C or more for 3 minutes, frost prevention mode will be released and compressor will restart its operation.</p> <p>② Overheating protection (Heating mode) The units is in six-minute resume prevention mode if pipe &lt;condenser / evaporator&gt; temperature is detected as over 70°C after the compressor started. Abnormal if the temperature of over 70°C is detected again within 10 minutes after six-minute resume prevention mode.</p>	<p>(Cooling or drying mode)</p> <p>① Clogged filter (reduced airflow) ② Short cycle of air path ③ Low-load (low temperature) operation beyond the tolerance range ④ Defective indoor fan motor • Fan motor is defective. • Indoor controller board is defective.</p> <p>⑤ Defective outdoor fan control ⑥ Overcharge of refrigerant ⑦ Defective refrigerant circuit (clogs)</p> <p>(Heating mode)</p> <p>① Clogged filter (reduced airflow) ② Short cycle of air path ③ Over-load (high temperature) operation beyond the tolerance range ④ Defective indoor fan motor • Fan motor is defective. • Indoor controller board is defective.</p> <p>⑤ Defective outdoor fan control ⑥ Overcharge of refrigerant ⑦ Defective refrigerant circuit (clogs) ⑧ Bypass circuit of outdoor unit is defective.</p>	<p>(Cooling or drying mode)</p> <p>① Check clogs of the filter. ② Remove shields.</p> <p>④ Measure the resistance of fan motor's winding. Measure the output voltage of fan's connector (FAN) on the indoor controller board. *The indoor controller board should be normal when voltage of AC 220~240V is detected while fan motor is connected. Refer to 9-7. ⑤ Check outdoor fan motor. ⑥⑦ Check operating condition of refrigerant circuit.</p> <p>(Heating mode)</p> <p>① Check clogs of the filter. ② Remove shields.</p> <p>④ Measure the resistance of fan motor's winding. Measure the output voltage of fan's connector (FAN) on the indoor controller board. *The indoor controller board should be normal when voltage of AC 220~240V is detected while fan motor is connected. Refer to 9-7. ⑤ Check outdoor fan motor. ⑥~⑧ Check operating condition of refrigerant circuit.</p>
P8	<p><b>Abnormality of pipe temperature</b> &lt;Cooling mode&gt; Detected as abnormal when the pipe temperature is not in the cooling range 3 minutes later of compressor start and 6 minutes later of the liquid or condenser/evaporator pipe is out of cooling range. Note 1) It takes at least 9 min. to detect. Note 2) Abnormality P8 is not detected in drying mode. Cooling range : -3 deg <math>\geq</math> (TH-TH1) TH: Lower temperature between: liquid pipe temperature (TH2) and condenser/evaporator temperature (TH5) TH1: Intake temperature</p> <p>&lt;Heating mode&gt; When 10 seconds have passed after the compressor starts operation and the hot adjustment mode has finished, the unit is detected as abnormal when condenser/evaporator pipe temperature is not in heating range within 20 minutes.</p> <p>Note 3) It takes at least 27 minutes to detect abnormality. Note 4) It excludes the period of defrosting (Detection restarts when defrosting mode is over) Heating range : 3 deg <math>\leq</math> (TH5-TH1)</p>	<p>① Slight temperature difference between indoor room temperature and pipe &lt;liquid or condenser / evaporator&gt; temperature thermistor • Shortage of refrigerant • Disconnected holder of pipe &lt;liquid or condenser / evaporator&gt; thermistor • Defective refrigerant circuit</p> <p>② Converse connection of extension pipe (on plural units connection) ③ Converse wiring of indoor/outdoor unit connecting wire (on plural units connection) ④ Defective detection of indoor room temperature and pipe &lt;condenser / evaporator&gt; temperature thermistor ⑤ Stop valve is not opened completely.</p>	<p>①~④ Check pipe &lt;liquid or condenser / evaporator&gt; temperature with room temperature display on remote controller and outdoor controller circuit board. Pipe &lt;liquid or condenser / evaporator&gt; temperature display is indicated by setting SW2 of outdoor controller circuit board as follows.</p> <p>(Conduct temperature check with outdoor controller circuit board after connecting 'A-Control Service Tool(PAC-SK52ST)').</p> <p>②③ Check converse connection of extension pipe or converse wiring of indoor/outdoor unit connecting wire.</p>



Error Code	Meaning of error code and detection method	Cause	Countermeasure
P9	<b>Abnormality of pipe temperature thermistor / Condenser-Evaporator (TH5)</b> ① The unit is in three-minute resume protection mode if short/open of thermistor is detected. Abnormal if the unit does not get back to normal within three minutes. (The unit returns to normal operation, if it has normally reset.) ② Constantly detected during cooling, drying, and heating operation (except defrosting) Short: 90°C or more Open: -40°C or less	① Defective thermistor characteristics ② Contact failure of connector (CN29) on the indoor controller board. (Insert failure) ③ Breaking of wire or contact failure of thermistor wiring. ④ Temperature of thermistor is 90°C or more or -40°C or less caused by defective refrigerant circuit. ⑤ Defective indoor controller board.	①—③ Check resistance value of thermistor. For characteristics, refer to (P1) above. ② Check contact failure of connector (CN29) on the indoor controller board. Refer to 9-7. Turn the power on and check restart after inserting connector again. ④ Operate in test run mode and check pipe <condenser / evaporator> temperature with outdoor controller circuit board. If pipe <condenser / evaporator> temperature is exclusively low (in cooling mode) or high (in heating mode), refrigerant circuit may have defective. ⑤ Operate in test run mode and check pipe <condenser / evaporator> temperature with outdoor control circuit board. If there is exclusive difference with actual pipe <condenser / evaporator> temperature replace indoor controller board. There is no abnormality if none of above comes within the unit. Turn the power off and on again to operate. ( In case of checking pipe temperature with outdoor controller circuit board, be sure to connect A-control service tool (PAC-SK52ST). )
E0 or E4	<b>Remote controller transmission error(E0)/signal receiving error(E4)</b> ① Abnormal if main or sub remote controller can not receive normally any transmission from indoor unit of refrigerant address "0" for three minutes. (Error code : E0) ② Abnormal if sub remote controller could not receive for any signal for two minutes. (Error code: E0) ① Abnormal if indoor controller board can not receive normally any data from remote controller board or from other indoor controller board for three minutes. (Error code: E4) ② Indoor controller board cannot receive any signal from remote controller for two minutes. (Error code: E4)	① Contact failure at transmission wire of remote controller ② All remote controllers are set as "sub" remote controller. In this case, E0 is displayed on remote controller, and E4 is displayed at LED (LED1, LED2) on the outdoor controller circuit board. ③ Mis-wiring of remote controller. ④ Defective transmitting receiving circuit of remote controller ⑤ Defective transmitting receiving circuit of indoor controller board of refrigerant address "0". ⑥ Noise has entered into the transmission wire of remote controller.	① Check disconnection or looseness of indoor unit or transmission wire of remote controller. ② Set one of the remote controllers "main". If there is no problem with the action above. ③ Check wiring of remote controller. • Total wiring length: max.500m (Do not use cablex 3 or more) • The number of connecting indoor units: max.16units • The number of connecting remote controller: max.2units When it is not the above-mentioned problem of ①~③ ④ Diagnose remote controllers. a) When "RC OK" is displayed, Remote controllers have no problem. Put the power off, and on again to check. If abnormality generates again, replace indoor controller board. b) When "RC NG" is displayed, Replace remote controller. c) When "RC E3" is displayed, d) When "ERC 00-06" is displayed, [ c),d)→Noise may be causing abnormality. ] * If the unit is not normal after replacing indoor controller board in group control, indoor controller board of address "0" may be abnormal.
E3 or E5	<b>Remote controller transmission error(E3)/signal receiving error(E5)</b> ① Abnormal if remote controller could not find blank of transmission path for six seconds and could not transmit. (Error code: E3) ② Remote controller receives transmitted data at the same time, compares the data, and when detecting it, judges different data to be abnormal 30 continuous times. (Error code: E3) ① Abnormal if indoor controller board could not find blank of transmission path. (Error code: E5) ② Indoor controller board receives transmitted data at the same time, compares the data, and when detecting it, judges different data to be abnormal 30 continuous times. (Error code: E5)	① Two remote controller are set as "main." (In case of 2 remote controllers) ② Remote controller is connected with two indoor units or more. ③ Repetition of refrigerant address. ④ Defective transmitting receiving circuit of remote controller. ⑤ Defective transmitting receiving circuit of indoor controller board. ⑥ Noise has entered into transmission wire of remote controller.	① Set a remote controller to main, and the other to sub. ② Remote controller is connected with only one indoor unit. ③ The address changes to a separate setting. ④~⑥ Diagnose remote controller. a) When "RC OK" is displayed, remote controllers have no problem. Put the power off, and on again to check. When becoming abnormal again, replace indoor controller board. b) When "RC NG" is displayed, replace remote controller. c) When "RC E3" or "ERC 00-66" is displayed, noise may be causing abnormality.



Error Code	Meaning of error code and detection method	Cause	Countermeasure
E6	<b>Indoor/outdoor unit communication error (Signal receiving error)</b> ① Abnormal if indoor controller board cannot receive any signal normally for six minutes after putting the power on. ② Abnormal if indoor controller board cannot receive any signal normally for three minutes. ③ Consider the unit abnormal under the following condition: When two or more indoor units are connected to one outdoor unit, indoor controller board cannot receive a signal for three minutes from outdoor controller circuit board, a signal which allows outdoor controller circuit board to transmit signals.	① Contact failure, short circuit or, mis-wiring (converse wiring) of indoor/outdoor unit connecting wire ② Defective transmitting receiving circuit of indoor controller board ③ Defective transmitting receiving circuit of indoor controller board ④ Noise has entered into indoor/outdoor unit connecting wire.	* Check LED display on the outdoor control circuit board. (Connect A-control service tool, PAC-SK52ST.) Refer to EA-EC item if LED displays EA-EC. ① Check disconnection or looseness of indoor/outdoor unit connecting wire of indoor unit or outdoor unit. Check all the units in case of twin triple indoor unit system. ②-④ Turn the power off, and on again to check. If abnormality generates again, replace indoor controller board or outdoor controller circuit board. * Other indoor controller board may have defective in case of twin triple indoor unit system.
E7	<b>Indoor/outdoor unit communication error (Transmitting error)</b> Abnormal if "1" receiving is detected 30 times continuously though indoor controller board has transmitted "0".	① Defective transmitting receiving circuit of indoor controller board ② Noise has entered into power supply. ③ Noise has entered into outdoor control wire.	①-③ Turn the power off, and on again to check. If abnormality generates again, replace indoor controller board.
Fb	<b>Abnormality of indoor controller board</b> Abnormal if data cannot be normally read from the nonvolatile memory of the indoor controller board.	① Defective indoor controller board.	① Replace indoor controller board.
E1 or E2	<b>Abnormality of remote controller control board</b> ① Abnormal if data cannot be normally read from the nonvolatile memory of the remote controller control board. (Error code: E1) ② Abnormal if the clock function of remote controller cannot be normally operated. (Error code: E2)	① Defective remote controller.	① Replace remote controller.
PA (2502) (2500)	<b>Forced compressor stop (due to water leakage abnormality)</b> ① When the intake temperature subtracted with liquid pipe temperature is less than -10°C, drain sensor is detected whether it is soaked in the water or not at the interval of 90 seconds. (Drain pump will start operating when the drain sensor is detected to be soaked in the water.) ② The unit has a water leakage abnormality when the following conditions, a and b, are satisfied while the above-mentioned detection is performed. a) The drain sensor is detected to be soaked in the water 10 times in a row. b) The intake temperature subtracted with liquid pipe temperature is detected to be less than -10°C for a total of 30 minutes. (When the drain sensor is detected to be NOT soaked in the water, the detection record of a and b will be cleared.) ③ The drain sensor detection is performed in operations other than cooling. (When the unit stops operating, during heating or fan operation, when the unit stops because of some abnormality) *Once the water leakage abnormality is detected, abnormality state will not be released until the main power is reset.	1) Drain pump trouble 2) Drain defective · Drain pump clogging · Drain pipe clogging 3) Open circuit of drain sensor side heater 4) Contact failure of drain sensor connector 5) Dew condensation on drain sensor · Drain water descends along lead wire. · Drain water waving due to filter clogging. 6) Extension piping connection difference at twin, triple, quadruple system. 7) Mis-wiring of indoor/ outdoor connecting at twin, triple, quadruple system. 8) Room temperature thermistor / liquid pipe temperature thermistor detection is defective.	Check the drain pump. Performance Please confirm whether water can be drained. Confirm the resistance of the drain sensor side heater. Check the connector contact failure. ① Check the drain sensor leadwire mounted. ② Check the filter clogging Check the piping connection. Check the indoor/ outdoor connecting wires. Check the room temperature display of remote controller. Check the indoor liquid pipe temperature display of outdoor controller board.

## 9-4. TROUBLESHOOTING BY INFERIOR PHENOMENA

Note: Refer to the manual of outdoor unit for the detail of remote controller.



Phenomena	Cause	Countermeasure
(1)LED2 on indoor controller board is off.	<ul style="list-style-type: none"> <li>• When LED1 on indoor controller board is also off.</li> </ul> <p>① Power supply of rated voltage is not supplied to outdoor unit.</p> <p>② Defective outdoor controller circuit board.</p> <p>③ Power supply of 220~240V is not supplied to indoor unit.</p> <p>④ Defective indoor power board.</p> <p>⑤ Defective indoor controller board.</p> <p><b>(For the separate indoor/outdoor unit power supply system)</b></p> <p>① Power supply of 220~240V AC is not supplied to indoor unit.</p> <p>② The connectors of the optional replacement kit are not used.</p> <p>③ Defective indoor controller board.</p> <p>④ Defective indoor power board.</p>	<p>① Check the voltage of outdoor power supply terminal block (L, N) or (L<sub>3</sub>, N).</p> <ul style="list-style-type: none"> <li>• When AC 220~240V is not detected. Check the power wiring to outdoor unit and the breaker.</li> <li>• When AC 220~240V is detected. —Check ② (below).</li> </ul> <p>② Check the voltage between outdoor terminal block S1 and S2.</p> <ul style="list-style-type: none"> <li>• When AC 220~240V is not detected. Check the fuse on outdoor controller circuit board.</li> <li>• Check the wiring connection.</li> <li>• When AC 220~240V is detected. —Check ③ (below).</li> </ul> <p>③ Check the voltage between indoor terminal block S1 and S2.</p> <ul style="list-style-type: none"> <li>• When AC 220~240V is not detected. Check indoor/outdoor unit connecting wire for mis-wiring.</li> <li>• When AC 220~240V is detected. —Check ④ (below).</li> </ul> <p>④ Check voltage output from CN2S on indoor power board (DC13.1V). Refer to 9-7-1.</p> <ul style="list-style-type: none"> <li>• When no voltage is output. Check the wiring connection.</li> <li>• When output voltage is between DC12.5V and DC13.7V. —Check ⑤ (below).</li> </ul> <p>⑤ Check the wiring connection between indoor controller board and indoor power board. Check the fuse on indoor controller board. If no problems are found, indoor controller board is defective.</p>
	<ul style="list-style-type: none"> <li>• When LED1 on indoor controller board is lit.</li> </ul> <p>① Mis-setting of refrigerant address for outdoor unit (There is no unit corresponding to refrigerant address "0".)</p>	<p>① Reconfirm the setting of refrigerant address for outdoor unit</p> <p>Set the refrigerant address to "0". (For grouping control system under which 2 or more outdoor units are connected, set one of the units to "0".)</p> <p>Set refrigerant address using SW1 (3-6) on outdoor controller circuit board.</p>


Note: Refer to the manual of outdoor unit for the detail of remote controller.

Phenomena	Cause	Countermeasure
<b>(2)LED2 on indoor controller board is blinking.</b>	<ul style="list-style-type: none"> <li>When LED1 on indoor controller board is also blinking. Connection failure of indoor/outdoor unit connecting wire</li> <li>When LED1 is lit.               <ul style="list-style-type: none"> <li>① Mis-wiring of remote controller wires Under twin triple indoor unit system, 2 or more indoor units are wired together.</li> <li>② Refrigerant address for outdoor unit is wrong or not set. Under grouping control system, there are some units whose refrigerant address is 0.</li> <li>③ Short-cut of remote controller wires</li> <li>④ Defective remote controller</li> </ul> </li> </ul>	<p>Check indoor/outdoor unit connecting wire for connection failure.</p> <ul style="list-style-type: none"> <li>① Check the connection of remote controller wires in case of twin triple indoor unit system. When 2 or more indoor units are wired in one refrigerant system, connect remote controller wires to one of those units.</li> <li>② Check the setting of refrigerant address in case of grouping control system. If there are some units whose refrigerant addresses are 0 in one group, set one of the units to 0 using SW1 (3-6) on outdoor controller circuit board.</li> <li>③④ Remove remote controller wires and check LED2 on indoor controller board.               <ul style="list-style-type: none"> <li>When LED2 is blinking, check the short-cut of remote controller wires.</li> <li>When LED2 is lit, connect remote controller wires again and: if LED2 is blinking, remote controller is defective; if LED2 is lit, connection failure of remote controller terminal block etc. has returned to normal.</li> </ul> </li> </ul>
<b>(3)Upward/downward vane performance failure</b>	<ul style="list-style-type: none"> <li>① The vane is not downward during defrosting and heat preparation and when the thermostat is OFF in HEAT mode. (Working of COOL protection function)</li> <li>② Vane motor does not rotate.               <ul style="list-style-type: none"> <li>Defective vane motor</li> <li>Breaking of wire or connection failure of connector</li> <li>Up/down vane setting is "No vanes".</li> </ul> </li> <li>③ Upward/downward vane does not work.               <ul style="list-style-type: none"> <li>The vane is set to fixed position.</li> </ul> </li> </ul>	<ul style="list-style-type: none"> <li>① Normal operation (The vane is set to horizontal regardless of remote control.)</li> <li>② Check ② (left).               <ul style="list-style-type: none"> <li>Check the vane motor. (Refer to "How to check the parts".)</li> <li>Check for breaking of wire or connection failure of connector.</li> <li>Check "Up/down vane setting". (Unit function selection by remote controller).</li> </ul> </li> <li>③ Normal operation (Each connector on vane motor side is disconnected.)</li> </ul>
<b>(4)Receiver for wireless remote controller</b>	<ul style="list-style-type: none"> <li>① Weak batteries of wireless remote controller.</li> <li>② Contact failure of connector (CNB) on wireless remote controller board. (Insert failure)</li> <li>③ Contact failure of connector (CN90) on indoor controller board.(Insert failure)</li> <li>④ Contact failure of connector between wireless remote controller board and indoor controller board.</li> </ul>	<ul style="list-style-type: none"> <li>① Replace batteries of wireless remote controller.</li> <li>②~④ Check contact failure of each connector. If no problems are found of connector, replace indoor controller board. When the same trouble occurs even if indoor controller board is replaced, replace wireless remote controller board.</li> </ul>

## 9-5. EMERGENCY OPERATION

### 9-5-1. When wireless remote controller troubles or its battery is exhausted

- Emergency operation is available in such a case using emergency operation switch equipped next to the receiver of indoor unit.
  - To start operation
    - Cooling Operation.....Press  (Cooling) switch.
    - Heating Operation.....Press  (Heating) switch.
- ※When the unit starts operating, the operation lamp is lit.



※Emergency operation will be performed as follows.

Mode	Cooling	Heating
Set temperature	24°C	24°C
Fan speed	High	High
Airflow direction	Horizontal (30deg)	Downward (70deg)

- To stop operation
  - Press either emergency operation switch (cooling/heating).

### 9-5-2. When wired remote controller or indoor unit micro computer troubles

- If there is not any other wrong when trouble occurs, emergency operation starts as the indoor controller board switch (SWE) is set to ON.
 




During the emergency operation the indoor unit is as follows;

(1) Indoor fan high speed operation                      (2) Drain pump operation
- When emergency operating for COOL or HEAT, setting of the switch (SWE) in the indoor controller board and outdoor unit emergency operation are necessary.
- Check items and notices as the emergency operation
  - Emergency operation cannot be used as follows;
    - When the outdoor unit is something wrong.
    - When the indoor fan is something wrong.
    - When drain over flow protected operation is detected during self-diagnosis. (Error code : P5)
  - Emergency operation will be serial operation by the power supply ON/OFF.
 

ON/OFF or temperature, etc. adjustment is not operated by the remote controller.
  - Do not operate for a long time as cold air is blown when the outdoor unit starts defrosting operation during heat emergency operation.
  - Cool emergency operation must be within 10 hours. Other wise, heat exchanger of indoor unit may get frosted.
  - After completing the emergency operation, return the switch setting, etc. in former state.
  - Since vane does not work at emergency operation, position the vane slowly by hand.

## 9-6. HOW TO CHECK THE PARTS

PLA-RP35AA.UK PLA-RP50AA.UK PLA-RP60AA.UK PLA-RP71AA.UK  
 PLA-RP100AA.UK PLA-RP125AA.UK PLA-RP140AA.UK  
 PLH-P35AAH.UK PLH-P50AAH.UK PLH-P60AAH.UK PLH-P71AAH.UK  
 PLH-P100AAH.UK PLH-P125AAH.UK PLH-P140AAH.UK

Parts name	Check points			
Room temperature thermistor (TH1)	Disconnect the connector then measure the resistance using a tester. (Surrounding temperature 10℃ ~30℃)			
Pipe temperature thermistor/liquid(TH2)	(Refer to the thermistor)			
Condenser/Evaporator temperature thermistor (TH5)				
Vane motor	Measure the resistance between the terminals using a tester. (Surrounding temperature20℃)			
Fan motor	Measure the resistance between the terminals using a tester. (Winding temperature 20℃)			
	Motor terminal or Relay connector	Normal		Abnormal
		PLA-RP35,50,60,71AA.UK PLH-P35,50,60,71AAH.UK	PLA-RP100,125,140AA.UK PLH-P100,125,140AAH.UK	
	Red-Black	87.2Ω	28.7Ω	Open or short
	White-Black	104.1Ω	41.6Ω	
	Drain pump	Measure the resistance between the terminals using a tester. (Winding temperature 20℃)		
	(Refer to the thermistor)			
				Normal
	Drain sensor	Measure the resistance between the terminals using a tester. Measure the resistance after 3 minutes have passed since the power supply was intercepted. (Surrounding temperature 0℃ ~60℃)		
	(Refer to the thermistor)			
				Normal
	0.6kΩ~6.0kΩ	Open or short		

# <Thermistor Characteristic graph>

## Thermistor for lower temperature

Room temperature thermistor (TH1)  
Pipe temperature thermistor/liquid (TH2)  
Condenser/evaporator temperature thermistor (TH5)

Thermistor  $R_0=15k\Omega \pm 3\%$   
Fixed number of  $B=3480 \pm 2\%$

$$R_t = 15 \exp \left\{ 3480 \left( \frac{1}{273+t} - \frac{1}{273} \right) \right\}$$

0°C	15kΩ
10°C	9.6kΩ
20°C	6.3kΩ
25°C	5.4kΩ
30°C	4.3kΩ
40°C	3.0kΩ


## Thermistor for drain sensor

Thermistor  $R_0=6.0k\Omega \pm 5\%$   
Fixed number of  $B=3390 \pm 2\%$


$$R_t = 6 \exp \left\{ 3390 \left( \frac{1}{273+t} - \frac{1}{273} \right) \right\}$$

0°C	6.0kΩ
10°C	3.9kΩ
20°C	2.6kΩ
25°C	2.2kΩ
30°C	1.8kΩ
40°C	1.3kΩ

## < Thermistor for lower temperature >




## < Thermistor for drain sensor >



## 9-7.TEST POINT DIAGRAM

### 9-7-1. Power board


PLA-RP35AA.UK PLA-RP50AA.UK PLA-RP60AA.UK PLA-RP71AA.UK  
 PLA-RP100AA.UK PLA-RP125AA.UK PLA-RP140AA.UK  
 PLH-P35AAH.UK PLH-P50AAH.UK PLH-P60AAH.UK PLH-P71AAH.UK  
 PLH-P100AAH.UK PLH-P125AAH.UK PLH-P140AAH.UK





## 9-7-2. Indoor controller board

PLA-RP35AA.UK PLA-RP50AA.UK PLA-RP60AA.UK PLA-RP71AA.UK  
 PLA-RP100AA.UK PLA-RP125AA.UK PLA-RP140AA.UK  
 PLH-P35AAH.UK PLH-P50AAH.UK PLH-P60AAH.UK PLH-P71AAH.UK  
 PLH-P100AAH.UK PLH-P125AAH.UK PLH-P140AAH.UK







## 9-8. FUNCTIONS OF DIP SWITCH AND JUMPER WIRE

Each function is controlled by the dip switch and the jumper wire on control p.c. board.






(Marks in the table below) Jumper wire (○ : Short × : Open)

Jumper wire	Functions	Setting by the dip switch and jumper wire	Remarks																																																																																																																									
SW1	Model settings	<table><tr><th>MODELS</th><th>Manufacture/Service</th></tr><tr><td>PLA-RP. AA</td><td><table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr><tr><td></td><td></td><td></td><td></td><td></td></tr><tr><td>ON</td><td>OFF</td><td>OFF</td><td>OFF</td><td>OFF</td></tr></table></td></tr><tr><td>PLH-P. AAH</td><td><table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr><tr><td></td><td></td><td></td><td></td><td></td></tr><tr><td>ON</td><td>OFF</td><td>OFF</td><td>OFF</td><td>OFF</td></tr></table></td></tr></table>	MODELS	Manufacture/Service	PLA-RP. AA	<table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr><tr><td></td><td></td><td></td><td></td><td></td></tr><tr><td>ON</td><td>OFF</td><td>OFF</td><td>OFF</td><td>OFF</td></tr></table>	1	2	3	4	5						ON	OFF	OFF	OFF	OFF	PLH-P. AAH	<table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr><tr><td></td><td></td><td></td><td></td><td></td></tr><tr><td>ON</td><td>OFF</td><td>OFF</td><td>OFF</td><td>OFF</td></tr></table>	1	2	3	4	5						ON	OFF	OFF	OFF	OFF																																																																																						
MODELS	Manufacture/Service																																																																																																																											
PLA-RP. AA	<table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr><tr><td></td><td></td><td></td><td></td><td></td></tr><tr><td>ON</td><td>OFF</td><td>OFF</td><td>OFF</td><td>OFF</td></tr></table>	1	2	3	4	5						ON	OFF	OFF	OFF	OFF																																																																																																												
1	2	3	4	5																																																																																																																								
ON	OFF	OFF	OFF	OFF																																																																																																																								
PLH-P. AAH	<table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr><tr><td></td><td></td><td></td><td></td><td></td></tr><tr><td>ON</td><td>OFF</td><td>OFF</td><td>OFF</td><td>OFF</td></tr></table>	1	2	3	4	5						ON	OFF	OFF	OFF	OFF																																																																																																												
1	2	3	4	5																																																																																																																								
ON	OFF	OFF	OFF	OFF																																																																																																																								
SW2	Capacity settings	<table><tr><th>MODELS</th><th>Manufacture/Service</th></tr><tr><td>PLA-RP35AA PLH-P35AAH</td><td><table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr><tr><td></td><td></td><td></td><td></td><td></td></tr><tr><td>ON</td><td>OFF</td><td>OFF</td><td>OFF</td><td>OFF</td></tr></table></td></tr><tr><td>PLA-RP50AA PLH-P50AAH</td><td><table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr><tr><td></td><td></td><td></td><td></td><td></td></tr><tr><td>ON</td><td>OFF</td><td>OFF</td><td>OFF</td><td>OFF</td></tr></table></td></tr><tr><td>PLA-RP60AA PLH-P60AAH</td><td><table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr><tr><td></td><td></td><td></td><td></td><td></td></tr><tr><td>ON</td><td>OFF</td><td>OFF</td><td>OFF</td><td>OFF</td></tr></table></td></tr><tr><td>PLA-RP71AA PLH-P71AAH</td><td><table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr><tr><td></td><td></td><td></td><td></td><td></td></tr><tr><td>ON</td><td>OFF</td><td>OFF</td><td>OFF</td><td>OFF</td></tr></table></td></tr><tr><td>PLA-RP100AA PLH-P100AAH</td><td><table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr><tr><td></td><td></td><td></td><td></td><td></td></tr><tr><td>ON</td><td>OFF</td><td>OFF</td><td>OFF</td><td>OFF</td></tr></table></td></tr><tr><td>PLA-RP125AA PLH-P125AAH</td><td><table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr><tr><td></td><td></td><td></td><td></td><td></td></tr><tr><td>ON</td><td>OFF</td><td>OFF</td><td>OFF</td><td>OFF</td></tr></table></td></tr><tr><td>PLA-RP140AA PLH-P140AAH</td><td><table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr><tr><td></td><td></td><td></td><td></td><td></td></tr><tr><td>ON</td><td>OFF</td><td>OFF</td><td>OFF</td><td>OFF</td></tr></table></td></tr></table>	MODELS	Manufacture/Service	PLA-RP35AA PLH-P35AAH	<table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr><tr><td></td><td></td><td></td><td></td><td></td></tr><tr><td>ON</td><td>OFF</td><td>OFF</td><td>OFF</td><td>OFF</td></tr></table>	1	2	3	4	5						ON	OFF	OFF	OFF	OFF	PLA-RP50AA PLH-P50AAH	<table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr><tr><td></td><td></td><td></td><td></td><td></td></tr><tr><td>ON</td><td>OFF</td><td>OFF</td><td>OFF</td><td>OFF</td></tr></table>	1	2	3	4	5						ON	OFF	OFF	OFF	OFF	PLA-RP60AA PLH-P60AAH	<table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr><tr><td></td><td></td><td></td><td></td><td></td></tr><tr><td>ON</td><td>OFF</td><td>OFF</td><td>OFF</td><td>OFF</td></tr></table>	1	2	3	4	5						ON	OFF	OFF	OFF	OFF	PLA-RP71AA PLH-P71AAH	<table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr><tr><td></td><td></td><td></td><td></td><td></td></tr><tr><td>ON</td><td>OFF</td><td>OFF</td><td>OFF</td><td>OFF</td></tr></table>	1	2	3	4	5						ON	OFF	OFF	OFF	OFF	PLA-RP100AA PLH-P100AAH	<table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr><tr><td></td><td></td><td></td><td></td><td></td></tr><tr><td>ON</td><td>OFF</td><td>OFF</td><td>OFF</td><td>OFF</td></tr></table>	1	2	3	4	5						ON	OFF	OFF	OFF	OFF	PLA-RP125AA PLH-P125AAH	<table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr><tr><td></td><td></td><td></td><td></td><td></td></tr><tr><td>ON</td><td>OFF</td><td>OFF</td><td>OFF</td><td>OFF</td></tr></table>	1	2	3	4	5						ON	OFF	OFF	OFF	OFF	PLA-RP140AA PLH-P140AAH	<table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr><tr><td></td><td></td><td></td><td></td><td></td></tr><tr><td>ON</td><td>OFF</td><td>OFF</td><td>OFF</td><td>OFF</td></tr></table>	1	2	3	4	5						ON	OFF	OFF	OFF	OFF	
MODELS	Manufacture/Service																																																																																																																											
PLA-RP35AA PLH-P35AAH	<table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr><tr><td></td><td></td><td></td><td></td><td></td></tr><tr><td>ON</td><td>OFF</td><td>OFF</td><td>OFF</td><td>OFF</td></tr></table>	1	2	3	4	5						ON	OFF	OFF	OFF	OFF																																																																																																												
1	2	3	4	5																																																																																																																								
ON	OFF	OFF	OFF	OFF																																																																																																																								
PLA-RP50AA PLH-P50AAH	<table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr><tr><td></td><td></td><td></td><td></td><td></td></tr><tr><td>ON</td><td>OFF</td><td>OFF</td><td>OFF</td><td>OFF</td></tr></table>	1	2	3	4	5						ON	OFF	OFF	OFF	OFF																																																																																																												
1	2	3	4	5																																																																																																																								
ON	OFF	OFF	OFF	OFF																																																																																																																								
PLA-RP60AA PLH-P60AAH	<table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr><tr><td></td><td></td><td></td><td></td><td></td></tr><tr><td>ON</td><td>OFF</td><td>OFF</td><td>OFF</td><td>OFF</td></tr></table>	1	2	3	4	5						ON	OFF	OFF	OFF	OFF																																																																																																												
1	2	3	4	5																																																																																																																								
ON	OFF	OFF	OFF	OFF																																																																																																																								
PLA-RP71AA PLH-P71AAH	<table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr><tr><td></td><td></td><td></td><td></td><td></td></tr><tr><td>ON</td><td>OFF</td><td>OFF</td><td>OFF</td><td>OFF</td></tr></table>	1	2	3	4	5						ON	OFF	OFF	OFF	OFF																																																																																																												
1	2	3	4	5																																																																																																																								
ON	OFF	OFF	OFF	OFF																																																																																																																								
PLA-RP100AA PLH-P100AAH	<table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr><tr><td></td><td></td><td></td><td></td><td></td></tr><tr><td>ON</td><td>OFF</td><td>OFF</td><td>OFF</td><td>OFF</td></tr></table>	1	2	3	4	5						ON	OFF	OFF	OFF	OFF																																																																																																												
1	2	3	4	5																																																																																																																								
ON	OFF	OFF	OFF	OFF																																																																																																																								
PLA-RP125AA PLH-P125AAH	<table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr><tr><td></td><td></td><td></td><td></td><td></td></tr><tr><td>ON</td><td>OFF</td><td>OFF</td><td>OFF</td><td>OFF</td></tr></table>	1	2	3	4	5						ON	OFF	OFF	OFF	OFF																																																																																																												
1	2	3	4	5																																																																																																																								
ON	OFF	OFF	OFF	OFF																																																																																																																								
PLA-RP140AA PLH-P140AAH	<table><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr><tr><td></td><td></td><td></td><td></td><td></td></tr><tr><td>ON</td><td>OFF</td><td>OFF</td><td>OFF</td><td>OFF</td></tr></table>	1	2	3	4	5						ON	OFF	OFF	OFF	OFF																																																																																																												
1	2	3	4	5																																																																																																																								
ON	OFF	OFF	OFF	OFF																																																																																																																								
J41 J42	Pair number setting with wireless remote controller	<table><tr><th rowspan="2">Wireless remote controller setting</th><th colspan="2">Control PCB setting</th></tr><tr><th>J41</th><th>J42</th></tr><tr><td>0</td><td>○</td><td>○</td></tr><tr><td>1</td><td>×</td><td>○</td></tr><tr><td>2</td><td>○</td><td>×</td></tr><tr><td>3 ~ 9</td><td>×</td><td>×</td></tr></table>	Wireless remote controller setting	Control PCB setting		J41	J42	0	○	○	1	×	○	2	○	×	3 ~ 9	×	×	<Settings at time of factory shipment> Wireless remote controller: 0 Control PCB: ○ (for both J41 and J42) Four pair number settings are supported. The pair number settings of the wireless remote controller and indoor control PCB (J41/J42) are given in the table on the left. ('×' in the table indicates the jumper line is disconnected.)																																																																																																								
Wireless remote controller setting	Control PCB setting																																																																																																																											
	J41	J42																																																																																																																										
0	○	○																																																																																																																										
1	×	○																																																																																																																										
2	○	×																																																																																																																										
3 ~ 9	×	×																																																																																																																										
JP1	Unit type setting	<table><tr><th>Model</th><th>JP1</th></tr><tr><td>Without TH5</td><td>○</td></tr><tr><td>With TH5</td><td>×</td></tr></table>	Model	JP1	Without TH5	○	With TH5	×	There is no jumper (JP1) because these models have the cond./eva. temperature thermistor (TH5).																																																																																																																			
Model	JP1																																																																																																																											
Without TH5	○																																																																																																																											
With TH5	×																																																																																																																											
JP3	Indoor controller board type setting	<table><tr><th>Indoor controller board type</th><th>JP3</th></tr><tr><td>Factory shipment</td><td>×</td></tr><tr><td>Service parts</td><td>○</td></tr></table>	Indoor controller board type	JP3	Factory shipment	×	Service parts	○																																																																																																																				
Indoor controller board type	JP3																																																																																																																											
Factory shipment	×																																																																																																																											
Service parts	○																																																																																																																											





Be careful on removing heavy parts.

OPERATING PROCEDURE	PHOTOS & ILLUSTRATIONS
<p><b>1. Removing the air intake grille</b></p> <ol style="list-style-type: none"> <li>(1) Slide the knob of air intake grille toward the arrow ① to open the air intake grille.</li> <li>(2) Remove drop prevention hook from the panel.</li> <li>(3) Slide the shaft in the hinge to the direction of the arrow ② and remove the air intake grille.</li> </ol>	<p><b>Figure 1</b></p> 
<p><b>2. Removing the fan guard</b></p> <ol style="list-style-type: none"> <li>(1) Open the air intake grille.</li> <li>(2) Remove the 3 screws of fan guard.</li> </ol>	<p><b>Photo 1</b></p> 
<p><b>3. Removing the room temperature thermistor</b></p> <ol style="list-style-type: none"> <li>(1) Remove the fan guard. (See photo 1)</li> <li>(2) Remove the screw in the room temperature thermistor holder to remove the holder and the room temperature thermistor.</li> <li>(3) Remove the 1 screw from the bell mouth, and unscrew the other 2 screws (fix to the oval hole which has a different diameter) to remove the bell mouth.</li> <li>(4) Hold the holder claw, and remove the room temperature thermistor and holder.</li> <li>(5) Disconnect the connector (red) from the indoor control board.</li> </ol>	<p><b>Photo 2</b></p> 
<p><b>4. Removing the electrical box</b></p> <ol style="list-style-type: none"> <li>(1) Remove the fan guard. (See photo 1)</li> <li>(2) Disconnect the lead wire of the vane motor from the clamp, and disconnect the white connector (10P).</li> <li>(3) Remove the room temperature thermistor with the holder.</li> <li>(4) Remove the bell mouth. (See photo 2)</li> <li>(5) Disconnect the relay connector in the electrical box.  Red (3P) for fan motor  White (2P) for pipe temperature detecting thermistor  Blue (3P) for drain pump  White (3P) for drain sensor  Green (6P) for auxiliary heater</li> <li>(6) Remove the 3 screws of the electrical box and loosen the other 2 screws to remove the box.  &lt;Electrical parts in the electrical box&gt;  Indoor controller board  Power supply board  Terminal block  Capacitor  Heater contactor</li> </ol>	<p><b>Photo 3</b></p> 





OPERATING PROCEDURE	PHOTOS & ILLUSTRATIONS
<p><b>5. Remove the fan motor</b></p> <ol style="list-style-type: none"><li>(1) Remove the fan guard.(See photo 1)</li><li>(2) Remove the bell mouth.(See photo 2)</li><li>(3) Remove the electrical box.(See photo 3)</li><li>(4) Remove the turbo fan nut.</li><li>(5) Pull out the turbo fan.</li><li>(6) Disconnect the connector of the fan motor lead wire.</li><li>(7) Remove the 4 nuts of the fan motor.</li></ol>	<p><b>Photo 4</b></p>  <p>Labels: Fan motor, Nut, Nuts, Connector</p>
<p><b>6. Removing the pipe temperature thermistor and condenser evaporator temperature thermistor</b></p> <ol style="list-style-type: none"><li>(1) Remove the fan guard.(See photo 1)</li><li>(2) Remove the bell mouth.(See photo 2)</li><li>(3) Remove the electrical box.(See photo 3)</li><li>(4) Remove the turbo fan.</li><li>(5) Remove the screw of the service panel.</li><li>(6) Remove the service panel.</li><li>(7) Remove the pipe temperature thermistor which is inserted into the holder installed to the thin copper pipe.</li><li>(8) Disconnect the 2-pin white connector.(CN21)</li></ol> <p><b>[Condenser/ evaporator temperature thermistor]</b></p> <ol style="list-style-type: none"><li>(9) Remove the drain pan. (See Photo 7)</li><li>(10) Remove the thermistor which is installed into the holder installed to the indoor coil.</li><li>(11) Disconnect the 2-pin black connector. (CN29)</li></ol>	<p><b>Photo 5</b></p>  <p>Labels: Pipe temperature thermistor, Service access</p>
<p><b>7. Removing the panel</b></p> <ol style="list-style-type: none"><li>(1) Remove the air intake grille.(See figure 1)</li></ol> <p><b>Corner panel (See figure 2)β</b></p> <ol style="list-style-type: none"><li>(1) Remove the corner screw.</li><li>(2) Slide the corner panel to the direction of the arrow③, and remove the corner panel.</li></ol> <p><b>Panel (See photo 6)</b></p> <ol style="list-style-type: none"><li>(1) Disconnect the connector that connects with the unit.</li><li>(2) Remove the 2 screws from the panel and loosen another 2 screws, which fix to the oval holes, have different diameters.</li><li>(3) Rotate the panel a little to remove the panel.</li></ol>	<p><b>Figure 2</b></p>  <p>Labels: Corner panel, Screw, Panel</p> <p><b>Photo 6</b></p>  <p>Labels: Connector, Screws, Panel</p>
<p><b>8. Removing the drain pan</b></p> <ol style="list-style-type: none"><li>(1) Remove the panel. (See photo 6)</li><li>(2) Remove the drain plug (Larger one), drain the remaining water in the drain pan.</li><li>(3) Remove the corner cover. (2 screws)</li><li>(4) Remove the bell mouth (See photo 2)</li><li>(5) Remove the electrical box. (See photo 3)</li><li>(6) Remove the lead wire holder. (1 screw)</li><li>(7) Remove the 4 screws and pull out the drain pan.</li></ol> <p>※ Pull out the left and right of the pan gradually. Be careful not to crack or damage the pan.</p>	<p><b>Photo 7</b></p>  <p>Labels: Screw, Drain pan, Lead wire holder, Drain plug(Larger), Corner cover</p>



OPERATING PROCEDURE	PHOTOS & ILLUSTRATIONS
<p><b>9. Removing the drain pump and drain sensor</b></p> <ol style="list-style-type: none"><li>(1) Remove the panel. (See photo 6)</li><li>(2) Remove the fan guard. (See photo 1)</li><li>(3) Remove the bell mouth. (See photo 2)</li><li>(4) Remove the electrical box. (See photo 3)</li><li>(5) Remove the drain pan. (See photo 7)</li><li>(6) Remove the 3 screws of the drain pump.</li><li>(7) Cut the drain hose band, pull out the drain hose from the drain pump.</li><li>(8) Pull out the drain pump.</li><li>(9) Remove the drain sensor and the holder.</li></ol>	<p><b>Photo 8</b></p> 
<p><b>10. Removing the heat exchanger</b></p> <ol style="list-style-type: none"><li>(1) Remove the panel. (See photo 6)</li><li>(2) Remove the fan guard. (See photo 1)</li><li>(3) Remove the bell mouth. (See photo 2)</li><li>(4) Remove the electrical box. (See photo 3)</li><li>(5) Remove the drain pan. (See photo 7)</li><li>(6) Remove the turbo fan. (See photo 4)</li><li>(7) Remove the 3 screws of the piping cover, and pull out piping cover.</li><li>(8) Remove the 4 screws of the outer wall cover, and pull out the outer wall cover.</li><li>(9) Remove the screw of the coil support.</li><li>(10) Remove the 2 screws of the coil.</li><li>(11) Pull out the heat exchanger.</li></ol>	<p><b>Photo 9</b></p>  <p><b>Photo 10</b></p> 
<p><b>11. Removing the heater</b></p> <ol style="list-style-type: none"><li>(1) Remove the panel. (See photo 6)</li><li>(2) Remove the electrical box. (See photo 3)</li><li>(3) Remove the bell mouth. (See photo 2)</li><li>(4) Remove the drain pan. (See photo 7)</li><li>(5) Remove the turbo fan. (See photo 4)</li><li>(6) Remove the 5 screws of the heater assembly.</li><li>(7) Remove the clamp (1 screw) securing the lead wire.</li><li>(8) Pull the heater assembly out.</li></ol>	

## PANEL PARTS

PLA-RP35AA.UK	PLH-P35AAH.UK
PLA-RP50AA.UK	PLH-P50AAH.UK
PLA-RP60AA.UK	PLH-P60AAH.UK
PLA-RP71AA.UK	PLH-P71AAH.UK
PLA-RP100AA.UK	PLH-P100AAH.UK
PLA-RP125AA.UK	PLH-P125AAH.UK
PLA-RP140AA.UK	PLH-P140AAH.UK



No.	Parts No.	Parts Name	Specifi- cation	Q'ty / set		Remarks (Drawing No.)	Wiring Diagram Symbol	Recom- mended Q'ty	Price	
				PLA-RP35,50,60,71,100,125,140AA.UK PLH-P35,50,60,71,100,125,140AAH.UK					Unit	Amount
				WIRED	WIRELESS					
1	S70 E10 003	AIR OUTLET GRILLE		1	1					
2	S70 E01 002	VANE ASSY		4	4					
3	S70 E01 638	CORNER PANEL		1	2					
4	S70 E00 638	CORNER PANEL		3	2					
5	S70 E00 500	L.L FILTER-A		1	1					
6	S70 E00 691	GRILLE ASSY		1	1					
7	S70 24K 658	RECEIVER			1		RU			
8	S70 E00 317	WIRELESS ADAPTER			1		W.B			
9	S70 E00 223	STEPPING MOTOR		4	4		MV			
10	S70 E00 063	VANE BUSH		8	8					
11	S70 E00 040	GEAR (VANE)		4	4					
12	S70 E01 040	GEAR		4	4					
13	S70 KW1 713	REMOTE CONTROLLER ASSY	PAR-21MAA-E	1			R.B			
14	S70 E15 714	WIRELESS REMOTE CONTROLLER ASSY	PAR-SL97A-E		1					
15	S70 58A 246	CORD		1						




## FUNCTIONAL PARTS

PLA-RP35AA.UK

PLA-RP50AA.UK

PLA-RP60AA.UK

PLA-RP71AA.UK




No.	Parts No.	Parts Name	Specifi- cation	Q'ty / set			Remarks (Drawing No.)	Wiring Diagram Symbol	Recom- mended Q'ty	Price	
				PLA-RP-AA.UK						Unit	Amount
				35,50	60	71					
1	S70 003 687	BASE		1	1	1					
2	S70 E01 130	LEG		2	2	2					
3	S70 005 688	DRUM 1 ASSY		1	1	1					
4	S70 E00 130	LEG		1	1	1					
5	S70 E00 114	TURBO FAN		1	1	1					
6	S70 08K 097	SPL WASHER / NUT		1	1	1					
7	S70 K16 480	HEAT EXCHANGER		1							
	S70 E17 480	HEAT EXCHANGER			1						
	S70 E40 480	HEAT EXCHANGER				1					
8	S70 E15 097	FLARE NUT	5/8"	1	1	1					
9	S70 17J 202	PIPE TEMPERATURE THERMISTOR		1	1	1		TH2			
10	S70 E20 202	CONDENSER EVAPORATOR TEMPERATURE THERMISTOR		1	1	1		TH5			
11	S70 E50 129	MOTOR CAP		1	1						
12	S70 E00 659	INNER COVER		1	1	1					
13	S70 E02 130	LEG		1	1	1					
14	S70 E06 762	FAN MOTOR	D17B6P70MS	1	1	1		MF			
15	S70 A41 105	MOTOR MOUNT		4	4	4					
16	S70 006 688	DRUM 2 ASSY		1	1	1					

## FUNCTIONAL PARTS

PLA-RP100AA.UK

PLA-RP125AA.UK

PLA-RP140AA.UK



No.	Parts No.	Parts Name	Specifi- cation	Q'ty / set		Remarks (Drawing No.)	Wiring Diagram Symbol	Recom- mended Q'ty	Price	
				PLA-RP.AA.UK					Unit	Amount
				100	125,140					
1	S70 003 687	BASE		1	1					
2	S70 E01 130	LEG		2	2					
3	S70 007 688	DRUM 1 ASSY		1	1					
4	S70 E00 130	LEG		1	1					
5	S70 E01 114	TURBO FAN		1	1					
6	S70 08K 097	SPL WASHER		1	1					
7	S70 K18 480	HEAT EXCHANGER		1						
	S70 K19 480	HEAT EXCHANGER			1					
8	S70 E16 097	FLARE NUT	3/4"	1	1					
9	S70 17J 202	PIPE TEMPERATURE THERMISTOR		1	1		TH2			
10	S70 E20 202	CONDENSER EVAPORATOR TEMPERATURE THERMISTOR		1	1		TH5			
11	S70 E50 129	MOTOR CAP		1	1					
12	S70 E02 659	INNER COVER		1	1					
13	S70 E02 130	LEG		1	1					
14	S70 E07 762	FAN MOTOR	D176P120MS	1	1		MF			
15	S70 A41 105	MOTOR MOUNT		4	4					
16	S70 008 688	DRUM 2 ASSY		1	1					



PLH-P35AAH.UK  
PLH-P50AAH.UK  
PLH-P60AAH.UK  
PLH-P71AAH.UK


41

## FUNCTIONAL PARTS

PLH-P100AAH.UK

PLH-P125AAH.UK


PLH-P140AAH.UK



No.	Parts No.	Parts Name	Specification	Q'ty / set		Remarks (Drawing No.)	Wiring Diagram Symbol	Recom- mended Q'ty	Price	
				PLH -P100 AAH.UK	PLH -P125,140 AAH.UK				Unit	Amount
1	S70 003 687	BASE		1	1					
2	S70 E01 130	LEG		2	2					
3	S70 007 688	DRUM 1 ASSY		1	1					
4	S70 E00 130	LEG		1	1					
5	S70 E01 114	TURBO FAN		1	1					
6	S70 08K 097	SPL WASHER		1	1					
7	S70 E06 300	HEATER ELEMENT	240V/867W	3			H1			
	S70 E05 300	HEATER ELEMENT	240V/1000W		3		H1			
8	S70 E21 480	HEAT EXCHANGER		1						
	S70 E25 480	HEAT EXCHANGER			1					
9	S70 17J 202	PIPE TEMPERATURE THERMISTOR		1	1		TH2			
10	S70 E20 202	CONDENSER EVAPORATOR TEMPERATURE THERMISTOR		1	1		TH5			
11	S70 20J 303	INSULATOR		1	1					
12	S70 46K 700	HEATER THERMAL SWITCH	50°C OFF	1	1		26H			
13	S70 E02 706	THERMAL FUSE	104°C, 16A	1	1		FS2			
14	S70 E04 706	THERMAL FUSE	72°C, 16A	1	1		FS1			
15	S70 E50 129	MOTOR CAP		1	1					
16	S70 E04 659	INNER COVER		1	1					
17	S70 E02 130	LEG		1	1					
18	S70 E07 762	FAN MOTOR	D176P120MS	1	1		MF			
19	S70 A41 105	MOTOR MOUNT		4	4					
20	S70 008 688	DRUM 2 ASSY		1	1					

## FUNCTIONAL PARTS

PLA-RP35AA.UK PLA-RP100AA.UK  
 PLA-RP50AA.UK PLA-RP125AA.UK  
 PLA-RP60AA.UK PLA-RP140AA.UK  
 PLA-RP71AA.UK



Part numbers that is circled is not shown in the figure.

No.	Parts No.	Parts Name	Specification	Q'ty / set				Remarks (Drawing No.)	Wiring Diagram Symbol	Recom- mended Q'ty	Price	
				PLA-RP - AA.UK							Unit	Amount
				35,50,60	71	100	125,140					
1	S70 E02 529	DRAIN PAN		1	1							
	S70 E00 529	DRAIN PAN				1						
	S70 E01 529	DRAIN PAN					1					
2	S70 29H 523	DRAIN SOCKET		1	1	1	1					
3	S70 E02 355	DRAIN PUMP		1	1	1	1		DP			
4	S70 E00 266	DRAIN SENSOR		1	1	1	1		DS			
5	S70 31K 241	DRAIN SENSOR HOLDER		1	1	1	1					
6	S70 E30 501	ELECTRICAL CONTROL BOX		1	1	1	1					
7	S70 K06 313	POWER BOARD		1	1	1	1		P.B			
8	S70 K80 310	INDOOR CONTROLLER BOARD		1	1	1	1		I.B			
9	S70 003 503	CONTROL COVER ASSY		1	1	1	1					
10	S70 E10 675	FAN GUARD		1	1	1	1					
11	S70 E00 202	ROOM TEMPERATURE THERMISTOR		1	1	1	1		TH1			
12	S70 512 716	TERMINAL BLOCK	2P (1, 2)	1	1	1	1		TB5			
13	S70 E01 716	TERMINAL BLOCK	3P (S1, S2, S3)	1	1	1	1		TB4			
14	S70 576 255	CAPACITOR	3μF 440V	1					C			
	S70 17T 255	CAPACITOR	3.5μF 440V		1				C			
	S70 E02 255	CAPACITOR	7μF 440V			1	1		C			
15	S70 001 663	CORNER COVER		1	1	1	1					
16	S70 A48 524	DRAIN PLUG		1	1	1	1					
17	S70 A41 524	DRAIN PLUG		1	1	1	1					
18	S70 A41 523	DRAIN HOSE ASSY		1	1	1	1					


## FUNCTIONAL PARTS

PLH-P35AAH.UK PLH-P100AAH.UK

PLH-P50AAH.UK PLH-P125AAH.UK

PLH-P60AAH.UK PLH-P140AAH.UK

PLH-P71AAH.UK



Part number that is circled is not shown in the figure.

No.	Parts No.	Parts Name	Specification	Q'ty / set				Remarks (Drawing No.)	Wiring Diagram Symbol	Recom- mended Q'ty	Price	
				PLH -P • AAH.UK							Unit	Amount
				35,50,60	71	100	125,140					
1	S70 E02 529	DRAIN PAN		1	1							
	S70 E00 529	DRAIN PAN				1						
	S70 E01 529	DRAIN PAN					1					
2	S70 29H 523	DRAIN SOCKET		1	1	1	1					
3	S70 E02 355	DRAIN PUMP		1	1	1	1		DP			
4	S70 E00 266	DRAIN SENSOR		1	1	1	1		DS			
5	S70 31K 241	DRAIN SENSOR HOLDER		1	1	1	1					
6	S70 E30 501	ELECTRICAL CONTROL BOX		1	1	1	1					
7	S70 K06 313	POWER BOARD		1	1	1	1		P.B			
8	S70 K80 310	INDOOR CONTROLLER BOARD		1	1	1	1		I.B			
9	S70 003 503	CONTROL COVER ASSY		1	1	1	1					
10	S70 E10 675	FAN GUARD		1	1	1	1					
11	S70 E00 202	ROOM TEMPERATURE THERMISTOR		1	1	1	1		TH1			
12	S70 512 716	TERMINAL BLOCK	2P (1, 2)	1	1	1	1		TB5			
13	S70 E01 716	TERMINAL BLOCK	3P (S1, S2, S3)	1	1	1	1		TB4			
14	S70 521 716	TERMINAL BLOCK	3P (L, N, ⊕)	1	1	1	1		TB2			
15	S70 71G 215	RELAY	JC-1A DC12V	1	1	1	1		88H			
16	S70 576 255	CAPACITOR	3μF 440V	1					C			
	S70 17T 255	CAPACITOR	3.5μF 440V		1				C			
	S70 E02 255	CAPACITOR	7.0μF 440V			1	1		C			
17	S70 001 663	CORNER COVER		1	1	1	1					
18	S70 A48 524	DRAIN PLUG		1	1	1	1					
19	S70 A41 524	DRAIN PLUG		1	1	1	1					
20	S70 A41 523	DRAIN HOSE ASSY		1	1	1	1					



**mitsubishi electric corporation**

HEAD OFFICE : MITSUBISHI DENKI BLDG., 2-2-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN