

# TECHNICAL & SERVICE MANUAL

## Series SLZ Ceiling Cassettes R410A

Indoor unit  
[Model names]

SLZ-KA25VA

SLZ-KA35VA

SLZ-KA50VA

SLZ-KA25VAL

SLZ-KA35VAL

SLZ-KA50VAL

[Service Ref.]

**SLZ-KA25VA.TH**

**SLZ-KA35VA.TH**

**SLZ-KA50VA.TH**


**SLZ-KA25VAL.TH**

**SLZ-KA35VAL.TH**

**SLZ-KA50VAL.TH**

Note :

- This manual does not cover outdoor units. When servicing outdoor units, please refer to the service manual No.OC322 together with this manual.



### CONTENTS

1. PART NAMES AND FUNCTIONS .....	2
2. SPECIFICATIONS .....	5
3. OUTLINES AND DIMENSIONS .....	7
4. WIRING DIAGRAM .....	10
5. REFRIGERANT SYSTEM DIAGRAM .....	11
6. TROUBLESHOOTING .....	12
7. 4-WAY AIR FLOW SYSTEM .....	19
8. DISASSEMBLY PROCEDURE .....	21
9. PARTS LIST .....	24

# 1


## PART NAMES AND FUNCTIONS

### Indoor Unit

SLZ-KA25VAL.TH SLZ-KA25VA.TH

SLZ-KA35VAL.TH SLZ-KA35VA.TH

SLZ-KA50VAL.TH SLZ-KA50VA.TH




### Wireless remote controller

SLZ-KA25VAL.TH

SLZ-KA35VAL.TH

SLZ-KA50VAL.TH



#### Attention :

● Avoid operation of buttons with fingernails or other sharp objects. Sharp objects may scratch remote controller.

## Wired remote controller


Once the controls are set, the same operation mode can be repeated by simply pressing the ON/OFF button.

SLZ-KA25VA.TH


SLZ-KA35VA.TH

SLZ-KA50VA.TH

### ● Operation buttons [ PAR-21MAA ]



## ● Display



### Caution

- Only the Power display lights when the unit is stopped and power supplied to the unit.
- When power is turned ON for the first time the (Centrally controlled) display appears to go off momentarily but this is not a malfunction.
- “NOT AVAILABLE” is displayed when the Air speed button are pressed. This indicates that this room unit is not equipped with the fan direction adjustment function and the louver function.
- When power is turned ON for the first time, it is normal that “PLEASE WAIT” is displayed on the room temperature indication (For max. 2minutes). Please wait until this “PLEASE WAIT” indication disappear then start the operation.

# 2

# SPECIFICATIONS

Indoor model			SLZ-KA25VAL.TH SLZ-KA25VA.TH	SLZ-KA35VAL.TH SLZ-KA35VA.TH	SLZ-KA50VAL.TH SLZ-KA50VA.TH	
Function			Cooling	Heating	Cooling	Heating
Power supply			Single phase 230V, 50Hz		Single phase 230V, 50Hz	
Capacity	Air flow (High/Medium/Low)	m <sup>3</sup> /h	600/540/480		660/540/480	
Electrical data	Power outlet	A	10		20	
	Running current *1	A	0.35		0.65	
	Power input Rated frequency	W	75		85	
	Dew prevention heater	(kW)	0.014		0.014	
	Power factor *1	%	90	93	94	94
	Fan motor current *1	A	0.19		0.27	
Fan motor	Model		PK6V15-LD		PK6V20-LL	
	Winding resistance (at20°C)	Ω	WHT-BLK : 407 BLK-BLU : 86 BLU-YLW : 30 BRN-RED : 165	WHT-BLK : 393 BLK-BLU : 164 BLU-YLW : 47 BRN-RED : 319	WHT-BLK : 325 BLK-BLU : 143 BLU-YLW : 47 BRN-RED : 309	
Dimensions	Width	mm(in)	UNIT : 570(22-7/16) PANEL : 650(25-9/16)			
	Height	mm(in)	UNIT : 208(8-3/16) PANEL : 20(13/16)			
	Depth	mm(in)	UNIT : 570(22-7/16) PANEL : 650(25-9/16)			
Weight		kg	UNIT : 16.5 PANEL : 3			
Special remarks	Air direction		4		4	
	Sound level(High/Medium/Low)	dB(A)	37/31/28		38/33/29	
	Fan speed(High/Medium/Low)	rpm	650/530/480		690/570/510	
	Fan speed regulator		3		3	
	Thermistor TH1(at25°C)	kΩ	10		10	
	Thermistor TH2(at25°C)	kΩ	10		10	
	Thermistor TH5(at25°C)	kΩ	10		10	

NOTE : Test conditions are based on ISO 5151  
 Cooling : Indoor D.B. 27°C W.B. 19°C  
 Outdoor D.B. 35°C W.B. 24°C  
 Heating : Indoor D.B. 20°C W.B. 15°C  
 Outdoor D.B. 7°C W.B. 6°C  
 Refrigerant piping length (one way): 5m  
 \*1 Measured under rated operating frequency.

## Specifications and rating conditions of main electric parts

### INDOOR UNIT


Item	Model	SLZ-KA25VAL.TH	SLZ-KA35VAL.TH	SLZ-KA50VAL.TH
		SLZ-KA25VA.TH	SLZ-KA35VA.TH	SLZ-KA50VA.TH
Indoor fan capacitor	(C1)	1.5μF 440V		
Fuse	(FUSE)	250V 6.3A		
Vane motor	(MV)	MSBPC20 12V 250Ω		
Terminal block	(TB)	TO OUTDOOR UNIT : 3P TO WIRED REMOTE CONTROLLER : 2P (SLZ-KA25/35/50VA.TH)		
Indoor fan motor thermal fuse		145°C ±2°C		
Cord Heater	(H2)	240V AC 15W		

# NOISE CRITERION CURVES

**SLZ-KA25VAL.TH**  
**SLZ-KA25VA.TH**

<50Hz>


NOTCH	SPL(dB)	LINE
High	37	○—○
Medium	31	△—△
Low	28	□—□



**SLZ-KA35VAL.TH**  
**SLZ-KA35VA.TH**

<50Hz>



NOTCH	SPL(dB)	LINE
High	38	○—○
Medium	33	△—△
Low	29	□—□



**SLZ-KA50VAL.TH**  
**SLZ-KA50VA.TH**

<50Hz>


NOTCH	SPL(dB)	LINE
High	39	○—○
Medium	34	△—△
Low	30	□—□





**NOTE:** The sound level is measured in an anechoic room where echoes are few, when compressor stops. The sound may be bigger than displayed level under actual installation condition by surrounding echoes. The sound level can be higher by about 2 dB than the displayed level during cooling and heating operation.

SLZ-KA25VAL.TH  
 SLZ-KA35VAL.TH  
 SLZ-KA50VAL.TH  
 SLZ-KA25VA.TH  
 SLZ-KA35VA.TH  
 SLZ-KA50VA.TH

Unit : mm





Models	Refrigerant pipe (liquid)	Refrigerant pipe (gas)
SLZ-KA25VA(L)	φ 6.35mm flared connection 1/4F	φ 9.52mm flared connection 3/8F
SLZ-KA35VA(L)	φ 6.35mm flared connection 1/4F	φ 9.52mm flared connection 3/8F
SLZ-KA50VA(L)	φ 6.35mm flared connection 1/4F	φ 12.7mm flared connection 1/2F



## WIRELESS REMOTE CONTROLLER

Unit : mm



### Installation area

- Area in which the remote controller is not exposed direct sunshine.
- Area in which there is no nearby heating source.
- Area in which the remote controller is not exposed to cold (or hot) winds.
- Area in which the remote controller can be operated easily
- Area in which the remote controller is beyond the reach of children.

### Installation method

- ① Attach the remote controller holder to the desired location using two tapping screws.
- ② Place the lower end of the controller into the holder.

- Ⓐ Wireless remote controller (Accessory)
- Ⓑ Wall
- Ⓒ Remote controller holder (Accessory)
- Ⓓ Fixing screw (Accessory)



- The signal can travel up to approximately 7 meters (in a straight line) within 45 degrees to both right and left of the center line of the receiver.  
In addition, the signal may not be received if there is interference of light of fluorescent lights or strong sunlight.





**WIRED REMOTE CONTROLLER**

Unit : mm






# 5

# REFRIGERANT SYSTEM DIAGRAM

SLZ-KA25VAL.TH SLZ-KA25VA.TH  
SLZ-KA35VAL.TH SLZ-KA35VA.TH  
SLZ-KA50VAL.TH SLZ-KA50VA.TH





## 6-1. Cautions on troubleshooting

### (1) Before troubleshooting, check the followings:

- ① Check the power supply voltage.
- ② Check the indoor/outdoor connecting wire for mis-wiring.


### (2) Take care the followings during servicing.

- ① Before servicing the air conditioner, be sure to first turn off the remote controller to stop the main unit, and then turn off the breaker.
- ② When removing the indoor controller board, hold the edge of the board with care NOT to apply stress on the components.
- ③ When connecting or disconnecting the connectors, hold the housing of the connector. DO NOT pull the lead wires.




## 6-2. Self-check

### 6-2-1. Wired remote controller




- |  |  |
|--|--|
| <p>① Turn on the power.</p> <p>② Press the [CHECK] button twice.</p> <p>③ Set refrigerant address with [TEMP] button if system control is used.</p> <p>④ Press the [ON/OFF] button to stop the self-check.</p> | <p>A CHECK button</p> <p>B Refrigerant address</p> <p>C TEMP. button</p> <p>D IC:Indoor unit<br/>OC:Outdoor unit</p> <p>E Check code</p> |
|--|--|

### 6-2-2. Wireless remote controller



OPERATION INDICATOR lamp




The following indication applies regardless of shape of the indicator


- ① Turn ON the power.
- ② During pressing both the MODE SELECT button and TOO COOL button on the remote controller at the same time, press the RESET button.
- ③ At first, release the RESET button.
- ④ And release the other two buttons since all LCD in operation display section of the remote controller is displayed after 3 seconds.
- ⑤ Transmit the signal of remote controller, pressing OPERATE/STOP (ON/OFF) button on the remote controller (The above procedure allows OPERATION INDICATOR lamp to indicate the failure-mode.)
- ⑥ Transmit the signal of remote controller, pressing OPERATE/STOP (ON/OFF) button to stop the self-check.

- Refer to the following tables for details on the check codes.

[Output pattern A]



[Output pattern B]



[Output pattern A] Errors detected by indoor unit

Wireless remote controller Beeper sounds/OPERATION INDICATOR lamp flashes (Number of times)	Wired remote controller ① Check code	Symptom	Remark
1	P1	Intake sensor error	
2	P2	Pipe (TH2) sensor error	
	P9	Pipe (TH5) sensor error	
3	E6, E7	Indoor/outdoor unit communication error	
4	P4	Drain sensor error	
5	P5	Drain pump error	
6	P6	Freeing/Overheating safeguard operation	
7	EE	Communication error between indoor and outdoor units	
8	P8	Pipe temperature error	
9	E4, E5	Remote controller signal receiving error	
10	-	-	
11	-	-	
12	Fb	Indoor unit control system error (memory error, etc.)	
-	E0, E3	Remote controller transmission error	
-	E1, E2	Remote controller control board error	

[Output pattern B] Errors detected by unit other than indoor unit (outdoor unit, etc.)

Wireless remote controller Beeper sounds/OPERATION INDICATOR lamp flashes (Number of times)	Wired remote controller ① Check code	Symptom	Remark
1	E9	Indoor/outdoor unit communication error (Transmitting error) (Outdoor unit)	For details, check the LED display of the outdoor controller board. As for outdoor unit, refer to service manual OC322.
2	UP	Compressor overcurrent interruption	
3	U3,U4	Open/short of outdoor unit thermistors	
4	UF	Compressor overcurrent interruption (When compressor locked)	
5	U2	Abnormal high discharging temperature/49C worked/insufficient refrigerant	
6	U1,Ud	Abnormal high pressure (63H worked)/Overheating safeguard operation	
7	U5	Abnormal temperature of heat sink	
8	U8	Outdoor unit fan safeguard stop	
9	U6	Compressor overcurrent interruption/Abnormal of power module	
10	U7	Abnormality of super heat due to low discharge temperature	
11	U9,UH	Abnormality such as overvoltage or voltage shortage and abnormal synchronous signal to main circuit/Current sensor error	
12	-	-	
13	-	-	
14	Others	Other errors (Refer to the technical manual for the outdoor unit.)	

\*1 If the beeper does not sound again after the initial two beeps to confirm the self-check start signal was received and the OPERATION INDICATOR lamp does not come on, there are no error records.

\*2 If the beeper sounds three times continuously "beep, beep, beep (0.4 + 0.4 + 0.4 sec. )" after the initial two beeps to confirm the self-check start signal was received, the specified refrigerant address is incorrect.

To be continued on the next page.

- On wireless remote controller
- ② The continuous buzzer sounds from receiving section of indoor unit.
- ③ Blink of operation lamp
- On wired remote controller
- ① Check code displayed in the LCD.

• If the unit cannot be operated properly after the above test run has been performed, refer to the following table to remove the cause.

Symptom		Cause
Wired remote controller	LED 1, 2 (PCB in outdoor unit)	
PLEASE WAIT	For about 2 minutes following power-on	After LED 1, 2 are lighted, LED 2 is turned off, then only LED 1 is lighted. (Correct operation)
PLEASE WAIT → Error code	After about 2 minutes has expired following power-on	Only LED 1 is lighted. → LED 1, 2 blink.
Display messages do not appear even when operation switch is turned ON (operation lamp does not light up).		Only LED 1 is lighted. → LED 1 blinks twice, LED 2 blinks once.

On the wireless remote controller with condition above, following phenomena takes place.

- No signals from the remote controller are accepted.
- OPE lamp is blinking.
- The buzzer makes a short piping sound.

**Note:**

**Operation is not possible for about 30 seconds after cancellation of function selection. (Correct operation)**

For description of each LED (LED1, 2, 3) provided on the indoor controller, refer to the following table.

LED1 (power for microcomputer)	Indicates whether control power is supplied. Make sure that this LED is always lit.
LED2 (power for remote controller)	Indicates whether power is supplied to the remote controller. This LED lights only in the case of the indoor unit which is connected to the outdoor unit refrigerant address "0".
LED3 (communication between indoor and outdoor units)	Indicates state of communication between the indoor and outdoor units. Make sure that this LED is always blinking.


### 6-3. Test point diagram

#### 6-3-1. Indoor power board


SLZ-KA25VAL.TH SLZ-KA25VA.TH

SLZ-KA35VAL.TH SLZ-KA35VA.TH

SLZ-KA50VAL.TH SLZ-KA50VA.TH







**6-3-2. Indoor controller board**  
**SLZ-KA25VAL.TH SLZ-KA25VA.TH**  
**SLZ-KA35VAL.TH SLZ-KA35VA.TH**  
**SLZ-KA50VAL.TH SLZ-KA50VA.TH**





**6-4. Trouble criterion of main parts**  
**SLZ-KA25VAL.TH SLZ-KA25VA.TH**  
**SLZ-KA35VAL.TH SLZ-KA35VA.TH**  
**SLZ-KA50VAL.TH SLZ-KA50VA.TH**

Part name	Check method and criterion																												
Room temperature thermistor (TH1)	Measure the resistance with a tester. (Part temperature 10°C ~ 30°C) <table border="1" style="margin: 10px auto;"> <thead> <tr> <th>Normal</th> <th>Abnormal</th> </tr> </thead> <tbody> <tr> <td>4.3kΩ~9.6kΩ</td> <td>Opened or short-circuited</td> </tr> </tbody> </table>				Normal	Abnormal	4.3kΩ~9.6kΩ	Opened or short-circuited																					
Normal					Abnormal																								
4.3kΩ~9.6kΩ					Opened or short-circuited																								
Pipe temperature thermistor/liquid (TH2)																													
Condenser/evaporator temperature thermistor (TH5)																													
Indoor fan motor (MF)  <p>BLK BLU YLW BRN RED ORN WHT            P : Thermal fuse 145 ± 2°C</p>	Measure the resistance between the terminals with a tester. (Coil wiring temperature 10°C ~ 30°C) <table border="1" style="margin: 10px auto;"> <thead> <tr> <th rowspan="2"></th> <th colspan="3">Normal</th> <th rowspan="2">Abnormal</th> </tr> <tr> <th>KA25VA(L)</th> <th>KA35VA(L)</th> <th>KA50VA(L)</th> </tr> </thead> <tbody> <tr> <td>WHT-BLK</td> <td>386~428Ω</td> <td>373~413Ω</td> <td>308~341Ω</td> <td rowspan="4">Opened or short-circuited</td> </tr> <tr> <td>BLK-BLU</td> <td>81~91Ω</td> <td>155~172Ω</td> <td>135~151Ω</td> </tr> <tr> <td>BLU-YLW</td> <td>28~32Ω</td> <td>44~49Ω</td> <td>44~49Ω</td> </tr> <tr> <td>BRN-RED</td> <td>157~174Ω</td> <td>302~335Ω</td> <td>293~324Ω</td> </tr> </tbody> </table>					Normal			Abnormal	KA25VA(L)	KA35VA(L)	KA50VA(L)	WHT-BLK	386~428Ω	373~413Ω	308~341Ω	Opened or short-circuited	BLK-BLU	81~91Ω	155~172Ω	135~151Ω	BLU-YLW	28~32Ω	44~49Ω	44~49Ω	BRN-RED	157~174Ω	302~335Ω	293~324Ω
	Normal			Abnormal																									
	KA25VA(L)	KA35VA(L)	KA50VA(L)																										
WHT-BLK	386~428Ω	373~413Ω	308~341Ω	Opened or short-circuited																									
BLK-BLU	81~91Ω	155~172Ω	135~151Ω																										
BLU-YLW	28~32Ω	44~49Ω	44~49Ω																										
BRN-RED	157~174Ω	302~335Ω	293~324Ω																										
Vane motor (MV) 	Measure the resistance between the terminals using a tester. (Surrounding temperature 20°C~30°C) <table border="1" style="margin: 10px auto;"> <thead> <tr> <th>Connector</th> <th>Normal</th> <th>Abnormal</th> </tr> </thead> <tbody> <tr> <td>Red — Yellow</td> <td rowspan="4">300Ω</td> <td rowspan="4">Open or short</td> </tr> <tr> <td>Red — Blue</td> </tr> <tr> <td>Red — Orange</td> </tr> <tr> <td>Red — White</td> </tr> </tbody> </table>				Connector	Normal	Abnormal	Red — Yellow	300Ω	Open or short	Red — Blue	Red — Orange	Red — White																
Connector	Normal	Abnormal																											
Red — Yellow	300Ω	Open or short																											
Red — Blue																													
Red — Orange																													
Red — White																													
Drain pump (DP) 	Measure the resistance between the terminals using a tester. (Surrounding temperature 20°C~30°C) <table border="1" style="margin: 10px auto;"> <thead> <tr> <th>Normal</th> <th>Abnormal</th> </tr> </thead> <tbody> <tr> <td>290Ω</td> <td>Open or short</td> </tr> </tbody> </table>				Normal	Abnormal	290Ω	Open or short																					
Normal	Abnormal																												
290Ω	Open or short																												
Drain sensor (DS) 	Measure the resistance between the terminals using a tester. Measure the resistance after 3 minutes have passed since the power supply was intercepted. (Surrounding temperature 0°C~60°C) <table border="1" style="margin: 10px auto;"> <thead> <tr> <th>Normal</th> <th>Abnormal</th> </tr> </thead> <tbody> <tr> <td>0.6kΩ~6.0kΩ</td> <td>Open or short</td> </tr> </tbody> </table> (Refer to the thermistor)				Normal	Abnormal	0.6kΩ~6.0kΩ	Open or short																					
Normal	Abnormal																												
0.6kΩ~6.0kΩ	Open or short																												

<Thermistor Characteristic graph>


Thermistor for lower temperature

- Room temperature thermistor (TH1)
- Pipe temperature thermistor/liquid (TH2)
- Condenser/evaporator temperature thermistor (TH5)

Thermistor  $R_0=15k\Omega \pm 3\%$   
 Fixed number of  $B=3480 \pm 2\%$

$$R_t=15\exp \left\{ 3480 \left( \frac{1}{273+t} - \frac{1}{273} \right) \right\}$$

0°C	15kΩ
10°C	9.6kΩ
20°C	6.3kΩ
25°C	5.2kΩ
30°C	4.3kΩ
40°C	3.0kΩ




Thermistor for drain sensor

Thermistor  $R_0=6.0k\Omega \pm 5\%$   
 Fixed number of  $B=3390 \pm 2\%$


$$R_t=6\exp \left\{ 3390 \left( \frac{1}{273+t} - \frac{1}{273} \right) \right\}$$

0°C	6.0kΩ
10°C	3.9kΩ
20°C	2.6kΩ
25°C	2.2kΩ
30°C	1.8kΩ
40°C	1.3kΩ
60°C	0.6kΩ



### 7-1. Fresh air intake (Location for installation)


At the time of installation, use the duct holes (cut out) located at the positions shown in following diagram, as and when required.



### 7-2. Fresh air intake amount & static pressure characteristics


SLZ-KA25VAL.TH SLZ-KA25VA.TH  
SLZ-KA35VAL.TH SLZ-KA35VA.TH  
SLZ-KA50VAL.TH SLZ-KA50VA.TH

#### Taking air into the unit



**NOTE:** Fresh air intake amount should be 20% or less of whole air amount to prevent dew dripping.

#### How to read curves



- Q...Planned amount of fresh air intake <m<sup>3</sup>/min>
- A...Static pressure loss of fresh air intake duct system with air flow amount Q <Pa>
- B...Forced static pressure at air conditioner inlet with air flow amount Q <Pa>
- C...Static pressure of booster fan with air flow amount Q <Pa>
- D...Static pressure loss increase amount of fresh air intake dust system for air flow amount Q <Pa>
- E...Static pressure of indoor unit with air flow amount Q <Pa>
- Qa...Estimated amount of fresh air intake with out D <m<sup>3</sup>/min>

### 7-3. Interlocking operation method with duct fan (Booster fan)

●Whenever the indoor unit is operating, the duct fan operates.



(1)Connect the optional multiple remote controller adapter(PAC-SA88HA-E)to the connector(CN51)on the indoor controller board.

(2)Drive the relay after connecting the 12V DC relay between the Yellow and Orange connector lines.

Use a relay under 1W.

MB: Electromagnetic switch power relay for duct fan.

X: Auxiliary relay (12V DC LY-1F)




## 7-4. Fixing of horizontal vane

Horizontal vane of each air outlet can be fixed according to the environment, which is installed.


### Setting procedure

- 1) Turn off a main power supply (Turn off a breaker).
- 2) Disconnect the vane motor connector of the direction of the arrow with pressing the unlocking button as shown in figure below.

Electricity insulate the disconnected connector with the vinyl tape.



- 3) Set a vertical vane of the air outlet, which tries to fixed by the hand slowly within the range in the table below.



### <Set range>

Standard of horizontal position	Level 30° (Min.)	Downward 45°	Downward 55°	Downward 70° (Max.)
Dimension A (mm)	21	25	28	30

\* Dimension between 21 mm and 30 mm can be arbitrarily set.

### Caution








Do not set the dimension out of the range.




Erroneous setting could cause dew drips, smudge on ceiling or malfunction of unit.

SLZ-KA25VAL.TH SLZ-KA35VAL.TH SLZ-KA50VAL.TH

Be careful on removing heavy parts.

OPERATING PROCEDURE	PHOTOS&ILLUSTRATIONS
<p><b>1. Removing the air intake grille</b></p> <ol style="list-style-type: none"> <li>(1) Slide the knob of air intake grille to the direction of the arrow ① to open the air intake grille.</li> <li>(2) Remove the hook for secure belt on air inlet grille from the panel.</li> <li>(3) Slide the shaft in the hinge to the direction of the arrow ② and remove the air intake grille.</li> </ol>	<p><b>Figure 1</b></p>  <p>Air intake grille Air intake grille knob Grille</p>
<p><b>2. Removing the fan guard</b></p> <ol style="list-style-type: none"> <li>(1) Open the air intake grille.</li> <li>(2) Remove the 3 screws of fan guard.</li> </ol>	<p><b>Photo 1</b></p>  <p>Fan guard Screws Air intake grille</p>
<p><b>3. Removing the panel</b></p> <ol style="list-style-type: none"> <li>(1) Remove the air intake grille. (Refer to 1)</li> </ol> <p><b>Corner panel (See figure 2)</b></p> <ol style="list-style-type: none"> <li>(1) Remove the screw of the corner.</li> <li>(2) Slide the corner panel to the direction of the arrow ③, and remove the corner panel.</li> </ol> <p><b>Panel (See photo 2)</b></p> <ol style="list-style-type: none"> <li>(1) Disconnect the connector that connects with the unit.</li> <li>(2) Remove the 2 screws from the panel and loose another 2 screws, which fixed to the oval hole, have different diameter.</li> <li>(3) Rotate the panel a little to remove the screws. (Slide the panel so that the screw comes to a large diameter of the oval hole, which has two different diameters.)</li> </ol>	<p><b>Figure 2</b></p>  <p>Corner panel Screw Panel Corner panel</p> <p><b>Photo 2</b></p>  <p>Panel Screws Connectors Screws</p>
<p><b>4. Removing the electrical parts</b></p> <ol style="list-style-type: none"> <li>(1) Remove the 2 screws and the control box cover. &lt;Electrical parts in the control box&gt; <ul style="list-style-type: none"> <li>• Indoor controller board (I.B)</li> <li>• Terminal block (TB4)</li> <li>• Indoor power board (P.B)</li> </ul> </li> </ol>	<p><b>Photo 3</b></p>  <p>Indoor power board (P.B) Indoor controller board (I.B) Terminal block (TB4)</p>



OPERATING PROCEDURE	PHOTOS&ILLUSTRATIONS
<p><b>5. Remove the room temperature thermistor (TH1)</b></p> <ol style="list-style-type: none"><li>(1) Remove the panel. (Refer to 3)</li><li>(2) Pull out the room temperature thermistor from the drain pan.</li><li>(3) Remove the 2 screws fixed to the control box cover, and remove the control box cover.</li><li>(4) Remove the connector (CN20) from the indoor controller board, and disconnect the room temperature thermistor.</li></ol>	<p><b>Photo 4</b></p>  <p>Connectors Control box Drain plug Screw Room temperature thermistor (TH1) Drain pan Fan guard Screw</p>
<p><b>6. Remove the drain pan</b></p> <ol style="list-style-type: none"><li>(1) Remove the panel. (Refer to 3)</li><li>(2) Remove the room temperature thermistor and the 2 lead wires held with fastener; wireless controller board relay connector (9P red) and panel relay connector (10P white).</li><li>(3) Remove the 4 screws fixed to the drain pan, and remove the drain pan.</li><li>(4) Remove the fan guard. (Refer to 2)</li></ol>	
<p><b>7. Removing the pipe temperature thermistor/liquid (TH2) and condenser/evaporator temperature thermistor (TH5)</b></p> <ol style="list-style-type: none"><li>(1) Remove the panel. (Refer to 3)</li><li>(2) Remove the drain pan. (Refer to 6)</li><li>(3) Disconnect the indoor coil thermistor from the holder.</li><li>(4) Remove the 3 screws fixed to the piping cover, and remove the piping cover. (See photo 9)</li><li>(5) Remove the 2 screws fixed to the control box cover, and remove the control box cover.</li></ol> <p><b>Pipe temperature thermistor/liquid (TH2)</b></p> <ol style="list-style-type: none"><li>(6) Remove the connector (CN21) from the indoor controller board, and disconnect the pipe temperature thermistor/liquid.</li></ol> <p><b>Condenser/evaporator temperature thermistor (TH5)</b></p> <ol style="list-style-type: none"><li>(6) Remove the connector (CN29) from the indoor controller board, and disconnect the condenser/evaporator temperature thermistor.</li></ol>	<p><b>Photo 5</b></p>  <p>Control box Pipe temperature thermistor/liquid (TH2) Condenser/evaporator temperature thermistor (TH5)</p>
<p><b>8. Remove the fan motor (MF)</b></p> <ol style="list-style-type: none"><li>(1) Remove the panel. (Refer to 3)</li><li>(2) Remove the drain pan. (Refer to 6)</li><li>(3) Remove the nut and the washer from the turbo fan, and remove the turbo fan.</li><li>(4) Remove the 2 screws fixed to the control box cover, and remove the control box cover.</li><li>(5) Disconnect the connectors of the (fan 1) and the (fan 2) from the indoor controller board.</li><li>(6) Remove the 3 screws fixed to the piping cover, and remove the piping cover. (See photo 9)</li><li>(7) Remove the 6 screws fixed to the flat plate, and remove the flat plate.</li><li>(8) Disconnect the lead wires to the direction of the fan motor, and remove the 3 nuts of the fan motor.</li></ol>	<p><b>Photo 6</b></p>  <p>Flat plate Screw Nut Fan motor (MF) Nut Screws Lead wires Screw Nut</p>


## OPERATING PROCEDURE

### 9. Removing the drain pump (DP) and drain sensor (DS)


- (1) Remove the panel. (Refer to 3 )
- (2) Remove the drain pan. (Refer to 6)
- (3) Remove the 2 screws fixed to the control box cover, and remove the control box cover.
- (4) Remove the connectors of the (CNP) and the (CN31) from the indoor controller board.
- (5) Remove the 1 screw fixed to the cover, and remove the cover.
- (6) Disconnect the lead wires to the direction of the drain pump.(See photo 7)
- (7) Remove the 3 screws of the drain pump.
- (8) Cut the drain hose band, pull out the drain hose from the drain pump.
- (9) Pull out the drain pump.
- (10) Remove the drain sensor and the holder.

## PHOTOS&ILLUSTRATIONS

**Photo 7**




**Photo 8**




### 10. Removing the heat exchanger

- (1) Remove the panel. (Refer to 3 )
- (2) Remove the drain pan. (Refer to 6)
- (3) Remove the nut and the washer from the turbo fan, and remove the turbo fan.
- (4) Remove the 2 screws fixed to the control box cover, and remove the control box cover.
- (5) Disconnect the connector of the (fan) from the indoor controller board.
- (6) Remove the 3 screws fixed to the piping cover, and remove the piping cover. (See photo 9)
- (7) Remove the pipe temperature thermistor/liquid and condenser/evaporator temperature thermistor. (Refer to 7)
- (8) Disconnect the lead wires to the direction of the fan motor.
- (9) Remove the 1 coil support screw, the 2 inside coil screws (See photo 10), and the 4 outside coil screws (See photo 9) from the heat exchanger, and remove the heat exchanger.


**Photo 9**



**Photo 10**




PANEL PARTS  
SLP-2AL  
SLP-2AA



No.	Parts No.	Parts name	Specification	Q'ty/set		Remarks (Drawing No.)	Wiring Diagram Symbol	Recom- mended Q'ty	Price	
				SLP-2AL	SLP-2AA				Unit	Amount
1	E07 103 003	AIR OUTLET GRILLE		1						
	E07 158 003	AIR OUTLET GRILLE			1					
2	E07 103 317	WIRELSS REMOTE CONTROL BOARD		1			W.B			
3	E07 103 037	AUTO VANE		4	4					
4	E07 103 975	CORNER PANEL		4	4					
5	E07 103 100	AIR FILTER		1	1					
6	E07 103 010	INTAKE GRILLE		1	1					
7	E07 103 303	VANE MOTOR		4	4		MV			
8	E07 103 044	VANE BUSH		8	8					
9	E07 103 031	GEAR (V)		4	4					
10	E07 103 032	GEAR (M)		4	4					



**ELECTRICAL PARTS**  
**SLZ-KA25VAL.TH SLZ-KA25VA.TH**  
**SLZ-KA35VAL.TH SLZ-KA35VA.TH**  
**SLZ-KA50VAL.TH SLZ-KA50VA.TH**



No.	Parts No.	Parts name	Specification	Q'ty/set						Remarks (Drawing No.)	Wiring Diagram Symbol	Recom- mended Q'ty	Price	
				SLZ-KA									Unit	Amount
				25	35	50	25	35	50					
1	E07 006 382	FUSE	250V 6.3A	1	1	1	1	1	1	FUSE				
2	E02 661 385	VARISTOR		1	1	1	1	1	1	ZNR				
3	E07 162 447	INDOOR CONTROLLER BOARD		1			1			I.B				
	E07 164 447	INDOOR CONTROLLER BOARD			1			1		I.B				
	E07 166 447	INDOOR CONTROLLER BOARD				1			1	I.B				
4	E07 162 375	TERMINAL BLOCK		1	1	1	1	1	1	3P	TB4			
5	E07 156 375	TERMINAL BLOCK					1	1	1	2P	TB15			
6	E07 154 440	INDOOR POWER BOARD		1	1	1	1	1	1	P.B				
7	E02 095 350	INDOOR FAN CAPACITOR	1.5 $\mu$ F/ 440VAC	1	1	1	1	1	1	C1				

**FUNCTIONAL PARTS**

SLZ-KA25VAL.TH


SLZ-KA35VAL.TH

SLZ-KA50VAL.TH

SLZ-KA25VA.TH

SLZ-KA35VA.TH

SLZ-KA50VA.TH





No.	Parts No.	Parts name	Specification	Q'ty/set						Remarks (Drawing No.)	Wiring Diagram Symbol	Recom- mended Q'ty	Price	
				SLZ-									Unit	Amount
				25	35	50	25	35	50					
				VAL.	TH		VA.	TH						
1	E07 104 290	BASE		1	1	1	1	1	1					
2	E07 104 124	DRUM-1		1	1	1	1	1	1					
3	E07 104 808	LEG-1		2	2	2	2	2	2					
4	E07 105 124	DRUM-2		1	1	1	1	1	1					
5	E07 140 620	INDOOR HEAT EXCHANGER		1			1							
	E07 141 620	INDOOR HEAT EXCHANGER			1			1						
	E07 142 620	INDOOR HEAT EXCHANGER				1			1					
6	E07 104 105	MOTOR MOUNT		3	3	3	3	3	3	3PCS/SET				
7	E07 162 300	INDOOR FAN MOTOR	PK6V15-LD	1			1				MF			
	E07 164 300	INDOOR FAN MOTOR	PK6V20-LL		1			1			MF			
	E07 166 300	INDOOR FAN MOTOR	PK6V20-LM			1			1		MF			
8	E07 104 816	FLAT PLATE		1	1	1	1	1	1					
9	E07 104 502	TURBO FAN		1	1	1	1	1	1					
10	E07 104 097	SPL WASHER		1	1	1	1	1	1					
11	E07 104 700	DRAIN PAN		1	1	1	1	1	1					
12	E07 154 308	ROOM TEMPERATURE THERMISTOR		1	1	1	1	1	1		TH1			
13	E07 104 520	FAN GUARD		1	1	1	1	1	1					
14	E07 104 524	DRAIN PLUG		1	1	1	1	1	1					
15	E07 104 648	COIL SUPPORT		1	1	1	1	1	1					
16	E07 154 309	CONDENSER / EVAPORATOR TEMPERATURE THERMISTOR		1	1	1	1	1	1		TH5			
17	E07 154 307	PIPE TEMPERATURE THERMISTOR / LIQUID		1	1	1	1	1	1		TH2			
18	E07 104 702	DRAIN HOSE		1	1	1	1	1	1					
19	E07 104 266	DRAIN SENSOR		1	1	1	1	1	1		DS			
20	E07 104 241	SENSOR HOLDER		1	1	1	1	1	1					
21	E07 104 355	DRAIN PUMP		1	1	1	1	1	1		DP			
22	E07 104 809	LEG-2		2	2	2	2	2	2					
23	E07 154 006	COVER (DRUM)		1	1	1	1	1	1					
24	E07 140 426	WIRELESS REMOTE CONTROLLER		1	1	1					W.R			
25	E02 527 083	REMOTE CONTROLLER HOLDER		1	1	1								
26	E07 159 426	REMOTE CONTROLLER					1	1	1					
27	E07 018 089	REMOTE CONTROLLER CABLE					1	1	1					

**Mr. SLIM**

 **MITSUBISHI ELECTRIC CORPORATION**  
HEAD OFFICE : MITSUBISHI DENKI BLDG., 2-2-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN