

PAC-SE5 | CRA

User Guide

CONTROLS



IF YOU ARE TOO
HOT PRESS



IF YOU ARE TOO
COLD PRESS



Operation Buttons

- | | |
|---|---|
| 1 | ON/OFF - Switches between run and stop.
The light flashes when a malfunction occurs. |
| 2 | TEMPERATURE SETTING -
Sets the room temperature: Range of temperature setting:
Cool/Dry: 19°C-30°C / Heat: 17°C-28°C / Auto: 19°C-28°C |
| 3 | FAN SPEED SETTING -
Models with 4 airflow speed settings: Hi / Mid-2 / Mid-1 / Low
Models with 2 airflow speed settings: Hi / Low |

Display

- | | |
|---|--|
| 4 | OPERATION MODE - Displays the operation status between Cool / Dry / Auto / Fan / Heat. Operation modes vary depending on the air conditioning system, Auto mode is available with the City Multi R2 and VWR2 series only. |
| 5 | POWER DISPLAY -
Displayed while the remote control is powered on. |
| 6 | CHECK - Displayed together with the address of the malfunctioning unit (3 digits) and an error code (4 digits). |
| 7 | Displays set temperature. |