

2-5. LOSSNAY remote controller for LGH-RVX-E [PZ-61DR-E]




■ Functions

Function (Communicating mode)	PZ-61DR-E
Fan speed selection	4 fan speeds
Ventilation mode selection	Energy recovery/Bypass/Auto
Night-purge (time)	Any time selectable
Night-purge (fan speed)	Selectable from 4 fan speeds
Dip-switch setting and function setting from RC	Yes
Bypass temp. free setting	Yes
Heater-On temp. free setting	Yes
Fan power up after installation	Yes
0 - 10VDC external input	Yes
ON/OFF timer	Yes
Auto-Off timer	Yes
Weekly timer	Yes
Operation restrictions (ON/OFF, Ventilation mode, fan speed)	Yes
Operation restrictions (Fan speed skip setting)	Yes
Screen contrast adjustment	Yes
Language selection	Yes (8 languages)
Initializing remote controller	Yes
Filter cleaning sign	Yes
Lossnay core cleaning sign	Yes
Error indication	Yes
Error history	Yes
OA/RA/SA temp. display	Yes

- Stand-alone LOSSNAY operation is possible by commands from a centralized controller or LOSSNAY remote controller. (AE-200E is a centralized controller that supports LOSSNAY operation.)
- The LOSSNAY remote controller is capable of changing the air flow and vent modes.
- All the wiring is cross-wiring that uses non-polar two wire system signal cables.
  - \* It is possible to use a LOSSNAY remote controller for LOSSNAY unit that is interlocked with other indoor units.
  - \* It is not possible to connect to LGH-RX5-E.

■ System example



■ External dimension

